

Smart Alec®

Version 3.0

User Manual

ADAPTIVE

© 1999-2000 Adaptive Micro Systems, Inc.

Part No. 9709-2030

8/11 /00

NOTE: Due to continuing product innovation, specifications in this document are subject to change without notice.

Copyright © 1997-2000 Adaptive Micro Systems, Inc. All rights reserved.

Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using the names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.

BetaBrite, BETA-BRITE, BIG DOT, POWERVIEW, and SMART ALEC are trademarks of Adaptive Micro Systems, Inc. registered in the United States Patent and Trademark Office.

ADAPTIVE, Alec, ALPHA, AlphAlert, AlphaNET, AlphaNET plus, AlphaNET plus II, ALPHAVISION, Automode, BetaBrite Director, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Solar and TimeNet are trademarks of Adaptive Micro Systems, Inc.

Visit us at our Internet World Wide Web site: <http://www.ams-i.com>

or e-mail us at sales@ams-i.com

Table of Contents

Installing Smart Alec software	5
Introduction to the Smart Alec software	6
Overview	6
Smart Alec applications	8
Flowchart for setting up and using Smart Alec	11
What's new in Smart Alec 3.0	14
Smart Alec basics	15
QuickStart: Sending a simple message	15
Starting the Smart Alec system	21
How the Smart Alec windows work	24
How Smart Alec uses variables.....	26
Working with Smart Alec application components.....	27
Shutting the Smart Alec system down	33
Setting up the Smart Alec system	37
Overview	37
Setting up the Smart Alec software	37
Identifying notification devices	38
Identifying variables	42
Establishing DDE input data sources	47
Establishing OPC input data sources	54
Importing external data using sockets	64
Managing the Smart Alec system	66
Creating messages	66
Using commands to control messages	76
Creating variable rules	83
Grouping notification devices.....	87
Grouping display commands	90
Advanced functions	93
System Administration	93
Security authorization	96
Creating user environments	102
Authorizing applications and application functions	108
Identifying notification device interfaces	114
Managing the log of Smart Alec system events.....	119
Appendices	123
Appendix 1: Smart Alec computer requirements.....	123
Appendix 2: Types of Notification Device Interfaces	124

Appendix 3: Understanding modes on signs	128
Appendix 4: Understanding line positions (Top, Middle, Bottom, Fill)	130
Appendix 5: Including graphics in Smart Alec messages	138
Appendix 6: Socket Interface	140
Appendix 7: Troubleshooting	152
Appendix 8: Glossary	158

Installing Smart Alec software

NOTE: Please be sure that your computer system meets the requirements for installation. These are listed in “Appendix 1: Smart Alec computer requirements” on page 123.

To install the Smart Alec system, insert the Smart Alec CD in your CD drive. The Smart Alec installation process will start automatically. Simply follow the on-screen instructions.

Table 1: Installation notes

Condition	Instructions
If the Smart Alec installation process does not start automatically...	...you can start it manually: 1. Select <i>Start > Run...</i> 2. Type <i>E:\setup.exe</i> where <i>E</i> is the letter of the CD ROM drive. 3. Click <i>OK</i>
If you already have Smart Alec installed on the computer...	...this version of Smart Alec will ask if you want to migrate your database. If you answer No, you will lose all data. It is also suggested that you back up your database before installing this version of Smart Alec. Should you have problems with migration, call Adaptive's Technical Support department at 1-800-558-7022.
If you get a message that the database cannot be migrated...	...it may be because there is more than one DDE source for providing data to the same variable. Please contact Adaptive Micro Systems' Technical Support department at 1-800-558-7022 for assistance.
If you get a message that you need to update your <i>Windows 95</i> computer for Y2K...	...run these programs (located on the CD) in this order: 1. <i>w95y2k.exe</i> 2. <i>w95ws2setup.exe</i> – Then manually reboot the computer. 3. <i>y2kvdhcp.exe</i> 4. <i>corpupd.exe</i>
If you have been using security authorization in the current system...	...after installation of this version, be sure to turn security on with authorization levels in the <i>System Administration</i> application. Refer to “System Administration” on page 93.
In order to use the online Help system for Smart Alec or to supply OPC data to Smart Alec...	...you must have <i>Microsoft Internet Explorer</i> installed on your computer. <i>Internet Explorer</i> is included on the Smart Alec installation CD.

Introduction to the Smart Alec software

Overview

Smart Alec is a software system that integrates data from many sources, and sends that data to ALPHA electronic signs, alphanumeric pagers, and email systems.

Input vs. output

Data can come into the system from many sources and can be in a variety of formats.

This data can be placed into messages which can be sent to a number of viewing destinations. These destinations are called “notification devices.” Messages can be sent to the notification devices in a number of ways.

Setup vs. management

Normally the applications that are needed to set up the Smart Alec system are available only to an administrator, while the applications needed for routine management of messaging needs are available to all users. In an environment where only one person is responsible for using Smart Alec, this user is also the administrator, with full access to all applications.

System security

Security for Smart Alec is available to be able to limit access to some features or functions. This security applies to Smart Alec applications and what users can do with the applications, either read-only (“Details”) or both read and update (“Update”) access. Security also applies to system resources, such as hardware and data. A user will be able to use an application or resource only if he has authorization greater than or equal to the level determined to be needed for that application or resource.

Administrator vs. user security

Security is available so that, for instance, applications needed only by the Smart Alec administrator (to set up the system) are not accessible by normal users (for general management of the system.)

Single-user vs. multi-user environments

A “single-user” environment in Smart Alec might have more than one user, but all users have full access rights to all applications, application functions, and system inputs and resources.

A “multi-user” environment is appropriate when users should not necessarily have access to the same applications and application functions; that is, access can be restricted for some users for applications, application functions, or system inputs or resources. For example, you may want to restrict a clerk’s authority and not allow that person to send messages to the signs on the production floor. But you would want the building security manager to be able to send a fire alarm to every sign. Also, you might not want either of these people to be able to set authority for other users.

Smart Alec applications

The applications (programs) available in Smart Alec and their respective functions are as follows.

SA Bar

The initial Smart Alec application from which you can start any other Smart Alec application for which you are authorized. See “Starting the Smart Alec system”, starting on page 21.

Notification Device Setup

Designate the names and properties to be used for places where messages will be displayed (i.e., signs, pagers, and email.) See “Identifying notification devices” starting on page 38.

Notification Device Group Manager

Designate groups of notification devices so a user can send a message to multiple devices simultaneously. See “Grouping notification devices”, starting on page 87.

Variable Setup

Designate variables to be available in Smart Alec. Variables represent values that can change at any time. These values come from data sources external to Smart Alec, using DDE, OPC, or sockets (see below.) When there is a change in a variable’s value, actions set up in *Variable Rule Manager* (see below) can be triggered and also where the value of the variable is included in a message, the value changes. See “Identifying variables”, starting on page 42.

Variable Rule Manager

Designate rules to govern variables, what is done with them, and what happens when their values change.

A rule is a pre-defined set of one or more conditions with possible resulting actions. A rule is associated with a variable and is implemented when the value of that variable changes. When the rule is implemented, its conditions are evaluated. Based on the result of that evaluation, the rule’s resulting actions may be initiated. See “Creating variable rules”, starting on page 83.

Message Manager

Define messages which can be displayed on notification devices. Messages can include text, graphics, formatting, variables, time, date, temperature, and animation. See “Creating messages”, starting on page 66.

Command Manager

Designate display commands which are used to add, delete, erase, or replace messages sent to notification devices. Commands can be triggered by a variable’s value or can be scheduled for a specific date and time or for a recurring time period. See “Using commands to control messages”, starting on page 76.

Display Command Group Manager

Designate logical groups of display commands so that you can then create another command to essentially issue a series of commands all at once. See “Grouping display commands”, starting on page 90.

DDE Data Source Setup

Designate what data will be coming from outside of Smart Alec using DDE (Dynamic Data Exchange), where it will come from, and what to do with it. This data can be used to provide the values for variables. See “Establishing DDE input data sources”, starting on page 47.

OPC Data Source Setup

Another way, besides DDE, to bring data into Smart Alec to provide values for variables is by using OPC (OLE for Process Control). See “Establishing OPC input data sources”, starting on page 54.

Socket data source setup

Sockets are a third way, besides DDE and OPC, to bring data into Smart Alec to provide values for variables. Smart Alec does not have a specific application for sockets, but there is a process to follow. See “Importing external data using sockets”, starting on page 64.

Smart Alec Shutdown

Close all of the Smart Alec applications that do the background processing. See “Shutting the Smart Alec system down”, starting on page 33.

System Administration

Used by the system administrator for system-wide or high-level settings. See “System Administration”, starting on page 93.

Application Security Setup

There are two applications which can be used to create a multi-user system with security capability: *Application Security Setup* and *User Account Security Setup*.

Application Security Setup designates what level of authorization is needed by any user to access specific applications and the functions in each. If the level of authorization assigned to a user is greater than or equal to the level of authorization needed, then access is granted. See “Authorizing applications and application functions”, starting on page 108.

User Account Security Setup

In a multi-user system, *User Account Security Setup* can be used to designate what level of authorization is granted to any user for applications, variables, commands, and notification devices. In other words, you decide if users can access a given resource (application, notification device, etc.) and what functions they can do with it. See “Creating user environments”, starting on page 102.


Notification Device Interface Setup


Designate the type of hardware the computer uses to send messages to notification devices. This is usually done with *Notification Device Setup* when designating notification devices, but can also be done separately. See “Identifying notification device interfaces”, starting on page 114.

Event Log Manager

View a log of all events that occur in Smart Alec. See “Managing the log of Smart Alec system events”, starting on page 119.

Flowchart for setting up and using Smart Alec






Page 93

Page 42

Page 47

Page 54

Page 64



What's new in Smart Alec 3.0

1. A separate system administration application is now available for system-wide or high-level settings. See “System Administration” on page 93.
2. Security has been set so that a single-user system is the default. You can set up a multi-user system at any time. To do so, see “System Administration” on page 93, “Creating user environments” on page 102, and “Authorizing applications and application functions” on page 108.
3. Interfaces for notification devices do not need to be set up before the notification devices themselves. There is one default interface of each type pre-installed. You can set up others if needed when you set up a notification device. See “Identifying notification devices” on page 38 and “Identifying notification device interfaces” on page 114.
4. Two types of variable rules have been removed: Counter Rule and Counter with Alarm Rule. The functionality for these has been included in the definition of the variable itself. See “Identifying variables” on page 42.
5. OPC (OLE for Process Control) has been added as a means to import data for variables. See “Establishing OPC input data sources” on page 54.
6. The method for including graphics in a message has been defined. See “Appendix 5: Including graphics in Smart Alec messages” on page 138.
7. The background processors have been redesigned so that most applications will operate more quickly.
8. Reported software inconsistencies have been resolved for better system performance.

Smart Alec basics

QuickStart: Sending a simple message

This section takes you through the process of setting up the minimum system to accomplish the task of sending a message immediately from the *Message Manager* through a wired connection to an ALPHA sign. (See “Appendix 2: Types of Notification Device Interfaces” starting on page 124 for descriptions of available connections.)

Log into Smart Alec

1. From the *Start* button, click *Programs > Smart Alec*.
2. The Smart Alec introductory splash screen will appear temporarily.
3. If the *Login* screen appears, as shown below, fill it in as appropriate. Then click on the *Login* button. (If you don't know how to fill in this screen, check with your Smart Alec administrator.)


NOTE

If you are the first or only person logging into the system, you will not see this screen. If you are the administrator and there are other users already set up in the system, accept “Alec” as the user name with no password, except if you know the password is different.


The screenshot shows a login dialog box with a teal header labeled 'Login'. Below the header, there are two input fields. The first is labeled 'User Name' and contains the text 'Alec'. The second is labeled 'Password' and is empty. At the bottom of the dialog, there are three buttons: 'Login', 'Change Password', and 'Cancel'.

Set up a wired connection

4. On the SA Bar, click once on the *System Setup* bar, then click once on *Notification Device Setup*.




5. Click on the *Add ALPHA SA device* button.




6. Fill in a name and description as desired. Specify the serial address of the sign. Choose "Serial Interface 1" for the *Interface Name*. Click the *Add* button.

NOTE: The serial address is displayed when the sign is powered up. Valid addresses for Smart Alec signs are 1 through 255. Zero is not a valid address. Use the hand-held Remote Control to change the address as needed.




Create a simple message


7. From the *System Use* group on the *SA Bar*, click once on *Message Manager*. A gray screen, like the one shown below, will appear the first time you start *Message Manager*. After you create one or more messages, when you start up *Message Manager*, it will show a white screen with the first message in the list of created messages.




8. Choose *File > New*.



9. Enter a name for the message. Click *OK*.




10. Type the message as shown below.




11. Choose *File > Update*.

12. You will be prompted to verify that you want to update this message. Select the OK button.




Run the message

13. From the *System Use* group on the SA Bar, click once on *Command Manager*. A screen like the one shown below will appear listing any existing commands. Choose the button for a new command.



14. By either typing or using the drop-down arrows to select from a list, fill in the information as shown below for the Line 1 production count on the Line 1 sign. Click the *Destination* button to bring up a list, and select a *Destination* by clicking on the Line 1 *Destination* and then on the double-arrow button. Then click *OK*. Leave the start and end dates as they show on your screen and also the start time, but specify end time as three minutes from your current time. See below.




Starting the Smart Alec system

Logging into Smart Alec

To log into the Smart Alec system:

1. From the *Start* button, click *Programs > Smart Alec*.
2. The Smart Alec introductory splash screen will appear temporarily.
3. Next, the *Login* screen will appear, as below.



NOTE: You will not see this screen if: 1) this is the first time you're starting Smart Alec after installation, or 2) you are the only user and have no password.

4. Type in your user name and password, and click on the *Login* button.
5. Processing applications are started and run in the background as needed. Also, the window called the *SA Bar* will appear for your use. (See "Using the SA Bar" below.)


NOTE: Even if you click *Cancel* in Step 3 above, the processing applications remain running. To shut them down, log into Smart Alec and click *Smart Alec Shutdown* on the *SA Bar*.

NOTE

If you are the first or only person logging into the system, or if you are the administrator, accept "Alec" as the user name with no password.

Using the SA Bar

The *SA Bar* is where you start all the Smart Alec applications for which you are authorized.



How to use the SA Bar

- Click on any of the button group bars to show the applications available within that group of applications. The button group bars slide up and down as needed to reveal component applications below each bar.
- Click once on any application to start that application.
- Use the *Close* button to close any currently-running Smart Alec user applications in addition to closing the *SA Bar*. See “Shutting the Smart Alec system down” on page 33.

NOTE: Background processors will remain running unless full shutdown procedures are followed.

Smart Alec applications in button group bars

System Setup

- Notification Device Setup
- Variable Setup
- DDE Data Source Setup
- OPC Data Source Setup

System Use

- Message Manager
- Command Manager
- Variable Rule Manager
- Notification Device Group Manager
- Display Command Group Manager
- Smart Alec Shutdown


Advanced

- System Administration
- User Account Security Setup
- Application Security Setup
- Notification Device Interface Setup
- Event Log Manager

How the Smart Alec windows work

The picture below is representative of the windows in Smart Alec. The table following indicates its features and functions.

Duplicate, Update/change, Details/view, and Delete are described generically below. The New/add Item function is described in general below, and is described in detail individually in the section for each Smart Alec application.




Sorting:

You can sort any column of data by double-clicking on its heading. The first double-click sorts ascending; the second sorts descending. If more than one column is selected, the right-most column is used for the sort.

Feature	Name	Function
A	Menu button	Pull-down menu for the application.
B	New item	Create a new item of this type. The properties will need to be filled in using the dialog box that appears. The icon for <i>New Item</i> may vary in some applications, and some applications have more than one type of new item.
C	Duplicate this item	Duplicate the item selected and show its properties so they can be changed as needed to create another item that is similar to the original.
D	Update this item	Show all properties for this item so they can be changed as needed. You can also access the screen to update an item by double-clicking to the left of the row. (Also see <i>Item selection</i> .)
E	Details	Show all properties for this item, but do not allow any updating.
F	Delete this item	Delete this item from Smart Alec.
G	Locate function	Use this after selecting a column to search for a specific value. Used in conjunction with <i>Locate value</i> . If more than one column is selected, the right-most column is used
H	Locate value	Type the value to search for. Used in conjunction with <i>Locate function</i> .
I	Minimize button	Put the application down to the <i>Windows</i> task bar.

Feature	Name	Function
J	Resize button	Toggle the size of the window.
K	Close button	Close this application.
L	Item selection	Click in this column to select the row for an item, or double-click to open the item. (Also see <i>Update this item.</i>) When a row is selected, you can right-click on the row to get a pop-up menu for all the file functions (new, update, etc.)
M	Right-click	Right-click on the name of the item to create a new item.
N	Row height	Click and drag the bottom edge of the row to adjust the height of the row.
O	Column width	Click and drag the right edge of the column to adjust the width of the column.

The picture below is representative of the add/update/details dialog boxes in Smart Alec. The table following indicates its features and functions.



Feature	Name	Description
A	Item name	Name of the item selected. Cannot be changed after the item is created. If you need to change it: duplicate the item, change the new item's name, then delete the original item.
B	Item properties	Must be added, can be updated with proper authorization, can not be updated in details mode. Completion of these properties can be by typing, or, in some cases, by using a <i>Drop-down selection</i> button. NOTE: Single quotes, such as in the middle of "John's sign" to show possession, can not be used.
C	Drop-down selection button	Allows selection of items already created.
D	Add/Update	Adds or updates this one item and exits this window. (N/A for details.)
E	Apply	Allows you to save the values for this item and then view/update the values for any other item of the same type. (N/A for details.)
F	Cancel	Exits this window without making any changes.

How Smart Alec uses variables

Variables are entities used in Smart Alec to represent values that can change at any time. The values can come from a number of places, such as a production line, a spreadsheet, and others. Some examples of variables are temperature, production speeds, counts, on/off settings, alarms, and security lock status. (See “Identifying variables” on page 42 for detailed instructions.)



In this example, the amount of sales (12,345) is the variable.

Rules (pre-defined conditions with resulting actions) can be set for governing what happens when the value of a variable changes.

Smart Alec constantly monitors variables for a change in their values. When there is a change, any rule associated with that variable will be analyzed and its actions may be triggered. Examples of possible actions include starting or stopping a message and updating the value of a variable if it is included in any message. (See “Managing the log of Smart Alec system events” on page 119 for detailed instructions.)

One of the most important concepts to understand is that you can use variables and variable rules to control things that happen in Smart Alec. Both a variable and a rule controlling the results of a change in its value can trigger an action in Smart Alec.

Working with Smart Alec application components

The functions for Duplicate, Update, Details, and Delete are similar in each Smart Alec application. This section describes these functions generically, using the *Variable Rule Manager* as an example for the application items.

Where an application's function differs from these generic functions, it is described in a section for that application. The function for Add is described for each application and gives explanations for all properties for the item being added.

Duplicating an item

NOTE

Since you can't change the name of an item with the *Update* function, use duplicating to rename an item:

1. Create a copy.
2. Rename it.
3. Delete the original.

You can duplicate any item and change the name and any properties.


1. Highlight the row for the item to copy. Then either choose *File > Duplicate*, click the *Duplicate* button, or right-click on the row and select *Duplicate...*

Duplicate button

Click in this column to select an item.


Command Name	Category	Action	Message Name	Destination	Recur rence	S
Delete all messages	Display Command	Erase all messages		Production		
Hammer 1 Pressure	Display Command	Add message	Hammer 1 Pressure	Production		
Line 1 Count	Display Command	Add message	Line 1 count	Production	Yes	0
Line 1 Defects	Display Command	Add message	Line 1 Defects	Warehouse 1 Alp	Yes	0
Line 2 Count	Display Command	Add message	Line 2 Count	Production	Yes	0
Line 2 Defects	Display Command	Add message	Line 2 Defects	Warehouse 2 Alp	Yes	0
Production goal-Line 1	Display Command	Add message	Production goal-Line	Group		
Total defects	Display Command	Add message	Total defects-L1&2	Group		

2. The window for adding an item will appear. Change the name of the item and any properties that are different.



3. Then click either *Add* or *Apply*. Clicking the *Add* button takes you out of the window for adding an item, and the new item is shown in the list. Clicking the *Apply* button adds the new item into the list, but leaves the dialog box open for additional editing if needed. To close the dialog box after using *Apply*, choose *Add* or *Cancel*. You will only see the new item in the list when you exit the window for adding an item, with either *Add* or *Cancel*.

- When the main window is displayed again, the new item is in the list.




Changing an item

- Highlight the row for the item to change. Then either choose *File > Update*, click the *Update* button, or right-click on the row and select *DupLiCate...*

Update button

Click in this column to select an item.



2. Make your changes. Then click *Update*.

Update Display Command

Command Name: Line 3 Count
Description: Line 3 production count
Action: Add message
Message Name: Line 3 Count
Execution Priority: 5
Run Priority: 5
Destination: Production
Owner: Public
 Schedule Command
Schedule Information:
Start Date: 5 / 4 /2000 Start Time: 6 :00:00 AM
End Date: 5 / 4 /2000 End Time: 3 :30:00 PM
Recurrence: Recurrence...
Update Apply Cancel

You can not change the item's *Name* here. You can change anything else.


Line 3 Count
Line 3 production count
Add message
Line 3 Count
5
5
Production
Private
2000 Start Time: 6 :00:00 AM
2000 End Time: 4 :00:00 PM
Update Apply Cancel

You can change more than one item in sequence this way:


1. Make the changes in the first item.
2. Click *Apply*.
3. Choose another item using the *Name* drop-down arrow.
4. Make changes in the new item.

Viewing details of an item

1. Highlight the row for the item to change. Then either choose *File > Details*, click the *Details* button, or right-click on the row and select *Details...*




2. The *Details* screen will appear. This simply shows the settings for the item. You can not change any of the settings here.



Deleting an item

1. Highlight the row for the item to change. Then either choose *File > Delete*, click the *Delete* button, or right-click on the row and select *Delete*.



2. You will be asked if you want to delete this item.
3. Choose *Yes* to delete the item.

Shutting the Smart Alec system down

From time to time, you may wish to shut down all or part of the Smart Alec system based on your own circumstances.

However, under the following conditions, you *must* shut down the Smart Alec system and then restart it before you can use the change:

1. After adding a notification device
2. After adding a notification device interface
3. After losing a connection to a device
4. After adding a DDE or OPC input data source


You *do not* need to shut down and restart Smart Alec under these conditions:

1. Adding or changing a variable
2. Adding or changing a message
3. After losing a connection to a DDE input data source

Individual user applications

To close any individual user application for setup and management of the system, use any of these methods:

- Click the *Close* button, available for all Smart Alec applications.
- Choose *Exit* from the application's *File* menu.
- Press Alt+F4.



All background processor applications

To close all of the Smart Alec applications that do the background processing, click *Smart Alec Shutdown* in the *System Use* button group on the *SA Bar*.



NOTE: Running *Smart Alec Shutdown* will stop all processing of messages and commands!

In *Windows*, you can see which programs are running by pressing **Ctrl/Alt/Del** together, but then be sure to choose *Cancel* here rather than *End Task* or *Shut Down*. Also be sure you don't press **Ctrl/Alt/Del** twice, rebooting the computer.


To restart the background processors, from the *Start* button, click *Programs > Smart Alec*.

All setup and manager user applications

To close all of the currently-running Smart Alec user applications for setup and use of the system (found in the *SA Bar*), close the *SA Bar* by any of the following methods.

NOTE: This will *not* close the Smart Alec background processor applications. (See the prior section.)

- Choose *Close* on the *SA Bar* menu.
- Click the *Close* button on the *SA Bar*.
- Press **Alt+F4**.



Complete Smart Alec system

1. Click *Smart Alec Shutdown* on the *SA Bar*.
2. Close the *SA Bar*.

Shutting the Smart Alec system down

Setting up the Smart Alec system

Overview

Typically, Smart Alec is used by only one person in an organization. Even if there is more than one person using Smart Alec, all users can be set up to have full access rights to all applications, application functions, and system inputs and resources. This setup is called a “single-user” system.

However, if there is more than one person using Smart Alec, your system may require security to be set so some users have *limited* usage and others have *unlimited* usage of Smart Alec. This setup is called a “multi-user” system. In a multi-user system, those users with limited usage of Smart Alec generally can only access applications for using the system, not those for setting up the system.

Setting up the Smart Alec software

A number of things must be set up in the Smart Alec environment for first-time use:

- Identify system resources (notification devices, notification device interfaces, and variables and possibly variable categories.)
- Establish input data sources, such as DDE, OPC or sockets.

Also, if this is a multi-user system:

- Create user environments.
- Authorize applications and application functions for each user.

The sections following explain what must be done.

NOTE

Default settings are provided for each system resource, user, and application.

Identifying notification devices



Notification Device Setup is used to designate the names and properties to be used for places where messages will be displayed (i.e., signs, pagers, and email).

Notification devices have properties. Examples of some properties that may be required are:

- Device name
- Description
- Address
- Notification device interface to use
- Pin number
- Packet size
- Authorization level

Accessing the Notification Device Setup application


From the *System Setup* group on the *SA Bar*, click once on *Notification Device Setup*. A screen like the one shown below will appear, listing any existing notification devices.




This column is available only if activated by the Smart Alec administrator.

Adding a notification device: ALPHA, pager, email

1. Choose the correct button for the type of notification device you wish to add.




2. For this example, we will add an ALPHA SA sign with a direct serial interface connection, as shown here. See the table below for explanations.



Item	Name	Description
A	Name	Name of the device as it will be known.
B	Description	Description of the device, for clarity. (Optional)
C	Address	Serial address assigned to the ALPHA SA sign. This is displayed when the sign is powered up and is set with a Remote Control. Zero is not a valid address.

Item	Name	Description
D	Interface name	Specific notification device interface to use with this notification device. The list of available interfaces includes those that are already set up and also those types of interfaces that can be set up (serial on specific COM ports, pager local on specific COM ports, pager wide area, or terminal server). If an interface is not already set up, it will be set up automatically, using defaults, when the notification device is added.
E	Additional properties	Depending on the type of notification device interface chosen, there may or may not be other properties to specify. These properties are set when a new notification device interface is set up. Some properties may be changed when a new notification device is set up. (To change notification device interface properties after set-up, see "Identifying notification device interfaces" on page 114.) Serial has no additional properties. Additional properties for local pager: <ul style="list-style-type: none"> • Pin # (Pager identification number) • Packet size (Contact your network administrator to determine this.) Additional properties for wide-area pager: <ul style="list-style-type: none"> • Pin # (Pager identification number) • Packet size (Contact your wide-area paging service to determine this.) NOTE: A wide area pager needs an attached modem. Additional properties for Terminal Server: <ul style="list-style-type: none"> • IP address (Internet Protocol address assigned to the terminal server) • Port Number (Must be 3001 if the terminal server is an Alpha Ethernet Adapter.)
F	Authorization level	Authorization level a user would need to access this notification device. (Available only if activated by the Smart Alec administrator.)
G	Advanced	Choose this button for more advanced functions. Only available for use with serial interfaces. See the next step.

3. For a new serial ALPHA SA notification device, the *Advanced* button is for these properties.



Item	Name	Description
A	Message confirmation	When <i>Message Confirmation</i> is enabled, the sign sends a response to the sender to confirm that the message has been received.
B	Time Out	The time, in seconds, to get a response from the device before timing out. (The <i>Message Confirmation</i> must be enabled.)

Settings for additional notification devices

In addition to the ALPHA SA device illustrated above, the settings below are available for pager and email devices.

Pager device

Item	Name	Description
A	Name	Name of the device as it will be known.
B	Description	Description of the device, for clarity. (Optional)
C	Interface name	Specific notification device interface. The only types available are pager local or pager wide area.
D	Pin #	Pager identification number
E	Packet size	For details, refer to the documentation for the pager or contact your network system administrator or wide-area paging service to determine this. To change this for an interface that's already set up, use <i>Notification Device Interface Setup</i> .
F	Notification device authorization level	Authorization level a user would need to access this notification device. (Available only if activated by the Smart Alec administrator.)

Email device

Item	Name	Description
A	Name	Name of the device as it will be known.
B	Description	Description of the device, for clarity. (Optional)
C	Email address	Destination address for the email message
D	Interface name	Specific notification device interface. To create a new interface for email, choose "Mapi Server". A new interface will be created using a name composed of the <i>Email profile</i> plus "Profile". For example, the interface for an email user named Joe would be called "Joe Profile".
E	Email profile	The network system name of the person to receive the email messages.
F	Email password *	The authorized password belonging to the <i>Email profile</i> .
G	Confirm new password *	Repeat the <i>Email password</i> , for confirmation.
H	Notification device authorization level *	Authorization level a user would need to access this notification device. (Available only if activated by the Smart Alec administrator.)


* Only available when setting up a new email interface.

Identifying variables

Variable Setup is used to designate real-time (“as it happens”) variables to be available in Smart Alec. Variables represent values that can change at any time. The values for the variable can come from a number of places outside of Smart Alec, such as a production line, a spreadsheet, manual data entry, and others. (For a more complete definition of variable, see page 163.)

Accessing the *Variable Setup* application

From the *System Setup* group on the *SA Bar*, click once on *Variable Setup*. A screen like the one shown below will appear, listing any existing variables.




NOTE: If you delete a variable which receives its value from an OPC data source, be sure to also delete the link to that OPC data source.

Adding a variable


1. Choose the button to add a new variable.

Add a variable



There are three tabs on the screen for adding a variable: “Details”, “Presentation”, and “Security”. (The “Security” tab is only available if activated by the Smart Alec administrator.) For this example, we will add a variable called “Speed-Line 1”, as shown here. See the table below each tab’s picture for explanations.

2. Complete the “Details” tab to set up basic information for the variable.



Item	Name	Description
A	Name	Name of the variable as it will be known
B	Description	Description of the variable, for clarity (Optional.)
C	Category	User-defined category for the variable (Optional.) (Available only if activated by the Smart Alec administrator.)

Identifying variables

Item	Name	Description
D	Padding	Determines the positioning and any fill characters for the value of the variable within a message. <ul style="list-style-type: none"> • Leading Spaces: Value is right-justified, filled with spaces (blanks) in front of the value. • Leading Zeros: Value is right-justified, filled with zeros in front of the value. • None: Value has no padding. Any extra spacing between the message and the variable's value is deleted. • Trailing Spaces: Value is left-justified, filled with spaces (blanks) after the value.
E	Number of characters to be displayed	Sets the length to be allocated for the value of the variable when used in a message. Maximum number of characters to allow for the length of the variable to display
F	Number of digits after decimal point	Sets the level of precision for fractional numbers If the value for the variable has a decimal, the <i>Number of digits after decimal point</i> indicates how many decimal places to use in the value for the variable. (For example, if the value for the variable has 5 characters with a <i>Number of digits after decimal point</i> of 2, then the number "123.456" would be displayed as "123.45". If the value for the variable has 6 characters with a <i>Number of digits after decimal point</i> of 4, then the number "123.456" would be displayed as "?3.456?".) NOTE: The <i>Number of digits after decimal point</i> setting is only available if the <i>Data Type</i> of the variable is float. Otherwise, you will not see this setting.
F	Data Type	Format of data for the variable: <ul style="list-style-type: none"> • Integer: a whole number (with no fraction) • Float: any number other than an integer. Can include decimals. • String: text, including alphabetic, numeric, and other characters


3. Complete the “Presentation” tab to indicate how the variable will appear in a message on a sign. The *Low Range* and *High Range* sections are optional.

The screenshot shows the 'Add Variables' dialog box with the 'Presentation' tab selected. The 'Trigger Variable' is set to 'Speed-Line 1'. The 'Low Range' section has a Limit of 5, Color of Yellow, and Flashing set to Default. The 'Normal' section has a Color of Green and Flashing set to Off. The 'High Range' section has a Limit of 10, Color of Red, and Flashing set to On. Arrows labeled A, B, C, and D point to the 'Trigger Variable', 'Low Range Limit', 'Low Range Color', and 'Low Range Flashing' fields respectively. Brackets labeled E, F, and G group the 'Low Range', 'Normal', and 'High Range' sections respectively.

Item	Name	Description
A	Trigger Variable	The variable to be used as the basis for setting range limits. The trigger variable defaults to the variable being set up. You can choose a different variable from the list to use as the trigger. Choosing a different variable would indicate that the value of the other variable is to be used as the trigger for the evaluation, but the value of the variable being set up is to be displayed.
B	Limit	Limit/threshold between this (high or low) range and the normal range
C	Color	Color to use for displaying the variable. “Default” uses whatever color state is set for the message immediately preceding the variable.
D	Flashing	Whether or not the variable will flash. “Default” uses whatever flashing state is set for the message immediately preceding the variable.
E	Low Range settings	(Optional) For a range lower than normal: <ul style="list-style-type: none"> • Whenever the value of the trigger variable is equal to or lower than the value set here, the variable will be displayed using the color and flashing settings for this low range. • Color to use for displaying the variable when in the low range • Whether or not the variable will flash when in the low range • “Default” uses whatever color or flashing state is set for the message immediately preceding the variable.

Item	Name	Description
F	Normal settings	For the normal range: <ul style="list-style-type: none"> • If Low Limit and/or High Limit are set, whenever the value of the trigger variable is higher than the low limit and/or lower than the high limit, the variable will be displayed using the color and flashing settings for this normal range. If no limit is set, color and flashing for the normal range apply to any value. • Color to use for displaying the variable when in the normal range • Whether or not the variable will flash when in the normal range • “Default” uses whatever color or flashing state is set for the message immediately preceding the variable.
G	High Range settings	(Optional) For a range higher than normal: <ul style="list-style-type: none"> • Whenever the value of the trigger variable is equal to or higher than the value set here, the variable will be displayed using the color and flashing settings for this high range. • Color to use for displaying the variable when in the high range • Whether or not the variable will flash when in the high range • “Default” uses whatever color or flashing state is set for the message immediately preceding the variable.

4. Complete the “Security” tab if your Smart Alec system is using Authorization Levels. This tab will not be present if the administrator has not set Authorization Levels on. (Refer to “Components of the System Administration window” on page 94.)



Item	Name	Description
A	Authorization Level	Security level needed to use the variable. Default is 5.

5. When all values are set, click *Add* (or *Apply*) and the new variable is displayed in the list of variables.

Establishing DDE input data sources

DDE Data Source Setup is used to designate what data will be coming from outside of Smart Alec using DDE (Dynamic Data Exchange), where it will come from, and how you want to use it. The link to this data is used to provide values for variables.


Smart Alec acts a DDE client. It needs a DDE server to communicate with in order to provide values for variables. Many existing programs already function as DDE servers, such as Wonderware's *Intouch* and *Microsoft Excel*. To use these or any other DDE-server applications with Smart Alec, you must use the service, topic, and item names which are to supply values for the variables from the DDE server. The DDE server application's documentation should provide these. (The discussion in the following sections uses *Microsoft Excel* as an example.)

After you establish a connection with the DDE server, the DDE server sends the value of the item to Smart Alec each time the item changes value.

NOTE: When using DDE, Smart Alec must be installed on the same computer as the external data source. When using NetDDE, Smart Alec must be installed on the same network as the external data source. In both cases, the source must be *Windows*-based.


Accessing the **DDE Data Source Setup** application

From the *System Setup* group on the *SA Bar*, click once on *DDE Data Source Setup*. A screen like the one shown below will appear, listing any existing DDE data sources.




Adding a link to a DDE data source

1. Choose the button to add a new DDE data source.



- For this example, we will add a link to a *Microsoft Excel* spreadsheet as DDE data source. See the table below for explanations.



Item	Name	Description
A	Smart Alec Variable to Update	The variable in Smart Alec for which this data will supply the value. The variable is automatically filled in with the last entry that was used. The variable must first be established before it can be selected here, but you can establish a new variable with the <i>New</i> button. See “Identifying variables” on page 42.
B	ASCII printable checkbox	ASCII control codes (non-printable characters) will be deleted before sending the data on to Smart Alec, leaving only data that is valid for presenting on a notification device. Valid only for a variable of “string” type. NOTE: All DDE data is restricted to 125 characters. If the value is longer, it will be truncated (cut off) to 125.
C	Server path	The full path to the file (or application, if not a specific file) for the DDE data source supplying the data. Smart Alec uses the server path to automatically start the server when Smart Alec starts. The server path is not mandatory if the server is always running before Smart Alec starts. If you’re using NetDDE with a source on a computer other than the one where Smart Alec is running, you do not need to include the server path, since Smart Alec can not start a source on a different computer. Therefore, when using NetDDE, the DDE server application must be running before the DDE link can be active. See “Accessing DDE input data” below. If the server is an application for which you have a specific file to use, you can include the full path to and including the file, in quotes, after the full path to the application, not in quotes. In this example, the <i>server path</i> is: C:\Program Files\Microsoft Office\Office\Excel.exe “C:\My Documents\Fiscal Report.xls”. The effect of this is that when Smart Alec is started, both the server and the specific file are automatically started along with Smart Alec.

Item	Name	Description
D	Service	Name of the application (not file) the data comes from. This may or may not be an executable program. Refer to the documentation or software vendor for your DDE server application to determine the correct <i>service</i> for that application. In this example, the <i>service</i> identifies the <i>Excel</i> application.
E	Topic	Refer to the documentation or software vendor for your DDE server application to determine the correct <i>topic</i> for that application. In this example, the <i>topic</i> identifies the specific worksheet within the <i>Excel</i> workbook specified in the <i>Server Path</i> .
F	Item	The specific piece of data to be used. In this case, the cell (row and column) is used.
G	Default Value	The value to be used for the variable when none is supplied by the DDE data link, such as if the DDE server stops running for any reason. Any values can be used if the data type is string. Any numeric values can be used for integer or float, but alphabetic and other special characters can not be used.
H	Filter On checkbox	Indicates that you want to filter the DDE data with a <i>Delta Value</i> . If you do not check this on, Smart Alec will update the value of the variable whenever the value changes, however small that change is. This may cause more processing than you want. Checking the <i>Filter On</i> checkbox and setting a <i>Delta Value</i> limits updating of the variable to when the change is greater than the “plus or minus” range. (NOTE: Some DDE server applications, such as <i>Microsoft Excel</i> , update <u>all</u> values whenever <u>any</u> of the values change.)
I	Delta Value	The number that is used to set a “plus or minus” range for the value of the variable. (So if the current value of the variable is 5 and the <i>Delta Value</i> is 2, then the range would be from 3 to 7.) The value of the variable is compared with this range. If the value of the variable is outside the range (higher or lower), then that value of the variable is used to update the variable wherever the variable is used for a command. Otherwise, the value of the variable is not updated.

An example using a Microsoft Visual Basic application

Below is an example specifying a *Visual Basic* application which processes data and provides that data directly to Smart Alec.

Setting	Value
Smart Alec Variable to Update	Hammer 1 pressure
ASCII printable checkbox	[N/A]
Server path	C:\Program Files\HighLevelTest.exe
Service	C:\Program Files\HighLevelTest.exe
Topic	Topic5
Item	Label1
Default Value	0
Filter On checkbox	[off]
Delta Value	[N/A]

An example using a Microsoft Access application

Below is an example specifying a *Microsoft Access* application which processes data and provides that data directly to Smart Alec.

Setting	Value
Smart Alec Variable to Update	Sales this month
ASCII printable checkbox	[N/A]
Server path	C:\Program Files\Microsoft Office\Office\MSACCESS.EXE
Service	MSAccess
Topic	Sales.mdb;SQL select Sales_This_Month from Sales_Table where Product = Widget
Item	data
Default Value	0
Filter On checkbox	[off]
Delta Value	[N/A]

Accessing DDE input data

When running and accessing a valid DDE source, DDEInputHandler.exe feeds data to the Smart Alec system and variables are updated.

For accessing DDE input data, DDEInputHandler must be running. (See “All background processor applications” on page 34.) When the Smart Alec system is started, DDEInputHandler.exe is started automatically and it starts the service application(s) that have been established. It tries to connect to the specified topics. Let Smart Alec start DDE server applications, since there will be a conflict if they are started before starting Smart Alec.

If you want to shut down and restart Smart Alec, you do not need to shut down DDE server applications which were originally started by Smart Alec, asf5.3972 0 TD(Ůn you

Establishing OPC input data sources

Introduction

OPC Data Source Setup is used in Smart Alec to designate what data will be coming from outside of Smart Alec using OLE for Process Control (OPC), where it will come from, and how you want to use it. The link to this data is used to provide values for variables.

Smart Alec acts as an OPC client. It needs an OPC server to communicate with in order to provide values for variables. Many existing programs already function as OPC servers, such as *Cimplicity*, *Steeplechase Visual Logic Controller*, or *Iconics*. To use these or any other OPC-server applications with Smart Alec, you must specify the OPC server and item names which are to supply values for the variables. The OPC server application's documentation should provide these.


General steps for communications using OPC data sources

In general, the steps for using OPC data servers with Smart Alec are as follows:

1. Be sure the OPC data server is installed and registered. When running and accessing a valid OPC source, it feeds data to the Smart Alec system and variables are updated. (Even if the OPC data server is installed and registered on a different computer, it must also be registered on the Smart Alec computer. Otherwise, you will be able to choose the OPC links to use in Step 3 but it won't work.)
2. Start and log into Smart Alec.
3. Establish the specific OPC links to use between Smart Alec and the external server. See the discussion below.
4. Smart Alec requests the data periodically.

Accessing the *OPC Data Source Setup* application

From the *System Setup* group on the *SA Bar*, click once on *OPC Data Source Setup* to display a screen like the one shown below, listing any existing OPC data sources.




NOTE: If you delete a variable which receives its value from an OPC data source, be sure to also delete the link to that OPC data source.


Adding a link to an OPC data source

1. Choose the button to add a new OPC data source (or choose *File > New*.)

Add an OPC data source.



2. For this example, we will add a link to specific pump speed data coming from an OPC server on a networked computer. See the table below for explanations.




Item	Name	Description
A	Smart Alec Variable to Update	The variable in Smart Alec for which this data will supply the value. The variable is automatically filled in with the last entry that was used. The variable must first be established before it can be selected here, but you can establish a new variable with the <i>New</i> button. See “Identifying variables” on page 42. NOTE: The same OPC server/item can be used to update more than one variable by creating more than one link.
B	OPC Server	Name of the OPC server sending the data, as well as the computer location if remote.
C	Item	The specific source of data to be used.
D	Default Value	The value to be used for the variable when none is supplied by the OPC data link, such as if the OPC server stops running for any reason. Can be any alphanumeric value/string.

Item	Name	Description
E	Filter On	Indicates that you want to filter the OPC data with a <i>Delta Value</i> . If you do not check this on, Smart Alec will update the value of the variable whenever the value changes, however small that change is. This may cause more processing than you want. Checking the <i>Filter On</i> checkbox and setting a <i>Delta Value</i> limits updating of the variable to when the change is greater than the “plus or minus” range. To limit processing, you can also use the <i>Update Rate</i> and <i>Dead Band</i> by clicking the <i>Advanced</i> button, described below.
F	Delta Value	<p>The smallest amount of change (“plus or minus”) necessary for a variable to be processed by Smart Alec. Similar to <i>Dead Band</i>, but is expressed as a specific number, applies to the Smart Alec server and to only one variable. (The <i>Filter On</i> box must be checked for <i>Delta Value</i> to be available.)</p> <p>The <i>Delta Value</i> number is used to set a range for testing the value of the variable. The prospective value of the variable is compared with this range. If the value of the variable is outside the range (higher or lower), then that value is used to update the variable wherever the variable is used. Otherwise, the variable is not updated.</p> <p>Example: If the current value of the variable is 5 and the <i>Delta Value</i> is 2, then the range would be from 3 to 7. If the OPC server sends a value of 8, Smart Alec will update the variable. If the OPC server sends a value of 6, Smart Alec will not update the variable.</p>
G	In Service	Indicates that the OPC server and item are to be considered active. If you have <i>In Service</i> un-checked, you can use <i>OPC Data Source Setup</i> to set up the server and item before they are actually active. Later, when they are validly active, return to this screen and make <i>In Service</i> checked. The OPC server and item will be recognized by Smart Alec automatically.
H	Advanced	Allows you to modify the <i>Update Rate</i> and <i>Dead Band</i> , which are properties for the entire group of OPC tags for Smart Alec. (See page 62.)


3. You can browse the network to select an OPC server and desired item. When the server and item are found, OPC considers an item to be a “tag” until the server and tag are connected to the Smart Alec system.

NOTE: You need to have *Microsoft Internet Explorer 4.0* or higher installed to use this function.




- When you locate the tag, highlight it and click OK. In this example, “\\” indicates that the server is on a remote computer, not the local computer where Smart Alec is running. Use care when typing the server name in by hand instead of browsing for it.




Filter allows you to use “wild card” (* and ?) characters to limit the list of available tags. For example, you could limit the list of tags shown here to only Ramp1 through Ramp5 by using a filter of “Ramp*”. Since only “*” is used here, all values are listed.



After clicking OK above, the Add OPC Link window shows Server and Item filled in.



- Next, choose a Smart Alec variable to associate with the OPC tag for updating. If you need to create a new variable, either 1) right-click on the *Smart Alec Variable to Update* and then choose *Add Variable* on the pop-up menu, or 2) click on the *New* button.



6. Complete the *Default Value*. Also, if you need to provide a *Delta Value* for numeric variables, check the *Filter On* box and then fill in the *Delta Value*.


The screenshot shows the 'Add OPC Link' dialog box with the following configuration:

- Smart Alec Variable to Update: Ramp1
- OPC Server: \\SAMS DN1\NICONICS.1
- Item: PLC.PHASED.Ramp1
- Default Value: 5
- Delta Value: 0.5
- Filter On:
- In Service:

Buttons at the bottom: Advanced..., Add, Apply, Cancel.

7. Advanced functions apply to the entire group of Smart Alec OPC links to this OPC server. When you change these, you are asked to confirm the change. See the picture and table below for explanations.

Establishing OPC input data sources



Item	Name	Description
A	Update Rate (ms)	The interval time, in milliseconds, for the OPC server to wait before updating the values of all the items in the entire Smart Alec group. In the example above, the updates would occur every 1000 milliseconds, which is once a second.
B	Dead Band (%)	The smallest percentage of change necessary for variables to be sent to Smart Alec by the OPC server. Similar to <i>Delta Value</i> , but is expressed as a percentage, applies to the OPC server and to all numeric variables in the Smart Alec group. Example: If the <i>Dead Band</i> is zero percent, the OPC server will not filter out any data, thus sending all data to Smart Alec. If the <i>Dead Band</i> is 50 percent, the OPC server will send changes for tag/items only if their values have changed by more than 50%. If the <i>Dead Band</i> is 100 percent, the OPC server will filter all data, thus sending none to Smart Alec.

- When all values are set, click *Add* (or *Apply*) and the new OPC link is shown in the list of links.

Add OPC Link

Smart Alec Variable to Update: Ramp1 [New...]

OPC Server: \\SAMS DN1\ICONICS.1 [Browse]

Item: PLC.PHASED.Ramp1

Default Value: 5

Delta Value: 0.5

Filter On

In Service

[Advanced...] [Add] [Apply] [Cancel]

OPC Data Source Setup

File View Help

OPC Server	Machine Name	Item Name	Variable Name	Delta Value	Filter On	In service
ICONICS.1	SAMS DN1	PLC.PumpSpeed	Pump Speed	0	No	Yes
ICONICS.1	SAMS DN1	PLC.PHASED.Ramp1	Ramp1	0.5	Yes	Yes

Importing external data using sockets

Sockets are a way (besides DDE and OPC) to import data into Smart Alec from external data sources, using a client/server relationship.

NOTE: There must be a user with a password in order to send data to Smart Alec using sockets. For information on how the user and password are used, see “Login Sequence” on page 141. For setting up users with passwords, see “Creating user environments” on page 102.


General steps for communications using sockets

In general, the steps for using sockets with Smart Alec are as follows:


1. Start and log into Smart Alec. See “Logging into Smart Alec” on page 21.
2. Establish the specific computer port number to use between Smart Alec and the external system. See “Setting the port number” below.
3. Initiate a socket connection between the systems.
4. Send data from the external data source to Smart Alec. For detailed instructions on using sockets to send data into the Smart Alec system, please see “Appendix 6: Socket Interface” on page 140.

Setting the port number

1. From the *Advanced* group on the *SA Bar*, click once on *System Administration*. A screen like the one shown below will appear.



2. The default port number for the Socket Handler connection is 8150. If you wish, you can type a different port number. Valid port numbers are 1025 and higher.



3. Click OK.

For more detailed information about using sockets for Smart Alec data, see “Appendix 6: Socket Interface” on page 140.

Managing the Smart Alec system

When using the Smart Alec system, you can:

- Create messages.
- Create and schedule commands for messages.
- Create rules for variables.
- Group notification devices and display commands.

Creating messages

A message is a unique, unified set (file) of information – a “thought”. It can be saved and/or sent to a notification device. Its “look and feel” is based on that specific device.

A message is defined using the *Message Manager*. It may include some or all of the following properties, either specified or defaulted:


- Text
- Formatting (modes, spacing, justification, font, color, width, height, flashing, true descenders)
- Objects (time, date, animation, temperature, counter)
- Variables
- Graphics (See “Appendix 5: Including graphics in Smart Alec messages” on page 138.)

A message does not include the following, which are designated using *Command Manager* for the message:

- Scheduling
- Destination
- Execution or Run Priority

Accessing the Message Manager application


From the *System Use* group on the *SA Bar*, click once on *Message Manager*. A gray screen, like the one shown below, will appear the first time you start *Message Manager*. After you create one or more messages, when you start up *Message Manager*, it will show the first message in the list.



NOTE: When you first create messages and the commands for them, you may want to practice with a few messages to achieve different effects on the notification device. You can use the preview function, described starting on page 70, for this.

Components of the Message Manager window

The picture below is representative of the *Message Manager* window. See the table below for explanations of the components.




Item	Name	Description
A	Message name	Name you want to give to the message.
B	Message selection	Drop-down box to select from the full list of created messages.
C	Preview button	Allows you to send the current message to the sign to see how it will appear. This temporarily overrides any other messages on the sign.
D	Mode button	Allows you to set modes, which are special effects that change the way a message appears on a sign, and the position of a message on the sign. <i>Mode</i> should always be the first setting in a message.
E	Mode pause (speed) button	Allows you to set the length of time to pause before repetition of this message.
F	Justification button	Allows you to set character spacing and left-, center-, or right-justification.
G	Fonts button	Allows you to select the font and the number of LED rows to use for characters that follow.
H	Color button	Allows you to set the color to use for whatever follows.
I	Width button	Allows you to set characters that follow to display as wide or double-wide.
J	Height button	Allows you to set characters that follow to display as double-high or not.
K	Flash button	Allows you to turn flashing on or off for whatever follows this control, until changed by another <i>Flash</i> control.


Item	Name	Description
L	True descenders button	Allows you to indicate that characters that follow are to be displayed using true descenders, so that, for instance, the tail of a “g” drops below the main base line of text.
M	New line/New page button	Allows you to indicate that whatever follows is to go on the next line or the next page of the sign.
N	Object button	Allows you to insert time, date, animation, and temperature. (Counter is also an option, but it is not used in the Smart Alec system.)
O	Variable button	Allows you to insert a placeholder for an existing variable.
P	Close box	Not available.
Q	Message area	Area for message text, variables, etc., as well as controls for the message and its contents.
R	Status bar	Indicates current status and error messages.
S	Cursor position indicator	Shows the position of the cursor in the message.
T	Date indicator	Shows the current date.
U	Time indicator	Shows the current time.

Creating a new message


1. Choose *File > New*.
2. Enter a name for the message. Click *OK*.



3. Use the *Message Manager* buttons and their pop-up screens to define the formatting and components of the message. An example is shown below.



4. Choose *File > Update*.
5. You will be prompted to verify that you want to update this message. Select the *OK* button.




Previewing a message

1. Click on the *Preview* button.




2. This gives a list of notification devices available for previewing. Messages can only be previewed on ALPHA SA signs. Choose the sign to which

you want to send the message. Then click on the *Send* button.




3. The message will appear on the chosen sign, temporarily overriding any other messages. When you are done previewing the message, click the *Done* button. Any other messages will resume display.




Selecting a different message


1. Click on the message selection drop-down box.



2. This gives a list of all the messages available. Click on the message you want to edit.



3. The message you choose is shown in the message name box and the message area.




Changing a message

1. Select the message to be changed.
2. Make the changes you need.
3. Choose *File > Update*.
4. You will be prompted to verify that you want to update this message. Select the *OK* button.

Deleting a message

1. Select the message to be deleted.
2. Choose *File > Delete*.
3. You will be prompted to verify the delete.



4. The message will be deleted and the next message in the list will be displayed in the *Message Manager*.

Displaying a message on a notification device

To actually display a message on a notification device, there must be a command for it and it must be scheduled. See “Using commands to control messages” on page 76.

Changing a message while it is being displayed


If a message is changed while it is being displayed, it will be displayed as changed under these conditions:

- a. If the command for it is time/date-based, the message will be displayed as changed after its command is deleted from and resent to the notification device with *Command Manager*.
- b. If the command for it is based on a variable, the message will be displayed as changed after a change in the value of the variable.


Checking the message syntax

“Syntax” refers to the construction of words, phrases, sentences, formatting codes, or messages according to established rules. The construction must be correct for a message to be displayed correctly. The *Message Manager* can check the syntax of messages for you. Follow the steps below to determine and fix any errors.


1. As an example, say you accidentally deleted the name of a variable to be used in a message.




2. Choose *Tools > Message Syntax Check*.



3. If there are errors, as there are here, a window will show the cursor position of the start of the error and when the process is complete.




4. Place the cursor in the message where indicated by the column number and message statistics.




5. Determine the error and correct it. It may be more efficient to delete the variable information

and re-enter it, since Smart Alec is sensitive to spelling.



6. When there are no errors in the message, the syntax check so indicates.



Using commands to control messages

A display command is used to control messages on a notification device. On notification devices, a display command can:


- Add a single message
- Delete a single message
- Erase all messages from the display
- Replace all messages with a single message

A display command can be implemented by scheduling it for a specific date and time or for a recurring time period. Scheduling is discussed below in this section.

A display command can also be implemented by setting up a Display Command Rule so that the value of a variable will trigger the command. See “Adding a display command rule” on page 84.

Accessing the Command Manager application

From the *System Use* group on the *SA Bar*, click once on *Command Manager*. A screen like the one shown below will appear listing any existing commands.



Command Manager

Command Manager


File View Help

Command Name	Category	Action	Message Name	Destination	Recurrence	Start time	Stop time	Description	Execution Priority	Run Priority
▶ L1 defects	Display Command	Add message	Line 1 defects	John Jones	Yes	6/4/00 6:30:00 AM	6/4/00 3:00:00 PM	Show Line 1 defects	5	5
L2 defects	Display Command	Add message	Line 2 defects	John Jones	Yes	6/4/00 3:00:00 PM	6/4/00 11:30:00 PM	Show Line 2 defects	5	5
L1 count	Display Command	Add message	Line 1 count	Group	Yes	6/4/00 8:30:00 AM	6/4/00 5:00:00 PM	Line 1 production count	5	5
L2 count	Display Command	Add message	Line 2 count	Group	Yes	6/4/00 8:30:00 AM	6/4/00 5:00:00 PM	Line 2 production count	5	5


Ready | [CAPS] | JINS | 6/2/00 | 1:17 PM

Adding a command

1. Choose the button to add a new command.




2. This example creates a command to add the message for the Line 1 production count on the Line 1 sign. The table below and the next steps explain each item and how to create it.



Item	Name	Description
A	Command Name	Name of the command.
B	Description	A more complete explanation of the command. (Optional)
C	Action	What you want to be done with the message(s): <ul style="list-style-type: none"> • Add a single message to the queue of all messages. • Delete a single message from the queue of all messages. • Erase all messages from the display. • Replace all messages with the single message specified.
D	Message Name	Select a message for the action. Valid for all <i>Actions</i> except "Erase all messages".
E	Execution Priority	The level of authority needed by a user to execute this command. The range of authority available to a user is determined by the Smart Alec administrator using <i>User Account Security Setup</i> . (Available only if activated by the administrator.)
F	Run Priority	The priority of this command on the display, to be compared with other commands being executed on that display. For example, a message with a <i>Run Priority</i> of 5 will override a message with a <i>Run Priority</i> of 6. (Available only if activated by the administrator.)
G	Destination button	Click this to bring up a list of available notification devices to select from.
H	Destination	The list of one or more notification devices selected for executing this command.
I	Owner	Specify who can access and use this command. (Available only if activated by the administrator.) <ul style="list-style-type: none"> • Public: This command can be used by anyone. Use this in a single-user system. • Private: This command can only be used by the person who created it. Use this only in a multi-user system.
J	Schedule Command checkbox	Check this on if you want to specify a time frame for this command. (Optional)
K	Schedule Information	Allows you to set the start date and time and end date and time.
L	Recurrence button	When the command is scheduled, you can click this button to bring up the options for repeating this command. The options are: <ul style="list-style-type: none"> • Daily (every x number of days or every weekday) • Weekly (every x number of weeks on specific days) • With an end date (none, after x number of occurrences, or by a specified date.)


3. Specify the *Command Name* and *Description*.
4. Choose an *Action* from the available options in the drop-down list.
5. Choose a *Message*, if applicable, from the available options in the drop-down list.
6. Set the *Execution Priority* and *Run Priority*.
7. Click the *Destination* button to bring up the list, as in the next step.

8. Select one or more *Destinations* by clicking (or Control-Click or Shift-Click) on a *Destination* and then on the double-arrow button. Then click *OK*.



NOTE
If you do not set a schedule for this command, you can implement the command using a display command rule. (See "Adding a display command rule" on page 84.)

9. Specify the Owner. (Available only if activated by the administrator.)
10. If you wish to specify a date and time for the command to be executed, click on the *Schedule Command checkbox*.
11. Next, set the schedule's *Start* and *End Date*. Do this by clicking on the down-arrow by the date. A monthly calendar will pop up. Select a date from the current month, or move to a different month with the left- or right-arrow. Click on the desired date on the calendar. It will be used for the schedule date. In this example, 8/7/00 is chosen for the start date, as in the picture below.



12. Complete the scheduling by setting the *Start* and *End Time*. Do this by clicking on each element of each time (that is, the hour, minute, or second) and then using the up- or down-arrows to increase or decrease the setting. You can also type the number.



NOTE
 If you set a schedule for this command, the Recurrence column in the main window will indicate either “yes” or “no”. If there is no schedule, it will be blank. (See the picture in “Accessing the Command Manager application” on page 76.)

13. You can set recurrence timing by clicking on the *Recurrence...* button. This gives these options:
- None
 - Daily (every x number of days or every weekday)
 - Weekly (every x number of weeks on specific days)
 - With an end date (none, after x number of occurrences, or by a specified date.)

After you set the recurrence options, click *OK*.

Recurrence Information Dialog

Recurrence pattern

None Every 1 day(s) Every weekday Daily Weekly

Range of recurrence

Start : 8 / 7 / 2000

No end date End after 1 occurrences End by 8 / 7 / 2000

OK Cancel

14. Click either *Add* or *Apply* for the *Add Display Command* window.
15. Command execution: If you do *not* set recurrence timing, the command will be executed for the scheduled date and time only. If you do not specify a schedule for this command, it will be executed based on a display command rule that must be set up for this command in *Variable Rule Manager*. (See “Adding a display command rule” on page 84.)

Creating variable rules

Variable Rule Manager is used to designate display command rules (pre-defined conditions with resulting actions) for how to use a variable to trigger a command to be issued. For more information, please see “How Smart Alec uses variables” on page 26.

A display command rule identifies variables to use as tools to trigger display commands, which, in turn, trigger actions, such as displaying a message, based on comparing the value of a variable with another value.

A display command rule is in the format of:


```
If <value1> compares favorably to
<criteria1>,
  (and/or <value2> compares favorably to
  <criteria2>)
  then do <display command>.
```

Examples:

1. If temperature of machine $\geq 212^\circ$, then display the “temperature alarm” message.
2. If counter = 1000, then display the “production goal” message.
3. If sales ≥ 1000 and net profit ≥ 1 million, then display the “congratulations” message.


Accessing the Variable Rule Manager

From the *System Use* group on the *SA Bar*, click once on *Variable Rule Manager*. A screen like the one shown below will appear, listing any existing variable rules.



Adding a display command rule

1. Choose the button to add a new display command rule.



2. Enter the information to define usage of this display command rule. The final result of this window creates a statement expressing a conditional command, that is, a command that will only be executed if all the preceding conditions are met. See the table below for explanations.

NOTE: Use care when setting this statement. If this statement is not set correctly, either nothing will happen or the wrong action will be taken.

The screenshot shows the 'Add Display Command Rule' dialog box. Callouts A through L point to the following elements:

- A:** Rule Name field (containing 'Defects:Lines 1 and 2')
- B:** Trigger Variable dropdown (containing 'Line 1 defects')
- C:** 'New...' button next to the Trigger Variable dropdown
- D:** Ownership radio buttons (Public and Private)
- E:** Description text area (containing 'Line 1 defects is critical; only total is tracked.'
- F:** The conditional logic text area (containing 'IF (Line 1 defects > 10) AND (Line 2 defects > 250) THEN Do Action Total defects')
- G:** 'IF' dropdown
- H:** 'Line 1 defects' dropdown
- I:** 'is greater than (>)' dropdown
- J:** '10' text field
- K:** 'AND' dropdown
- L:** 'Line 2 defects' dropdown

Each row of this table creates a phrase in the conditional command statement.

Additional controls include a 'Check here if you would like the second operand to be a variable' checkbox and 'Add', 'Apply', and 'Cancel' buttons at the bottom.

Item	Name	Description
A	Rule name	Type the name by which the rule is to be called.
B	Trigger Variable	Select the variable to be used to start this rule's test.
C	New	Use this button when you need to create a new variable to use as the trigger for the rule's evaluation.
D	Ownership	Specify who can access and use this rule. (Available only if activated by the administrator.) <ul style="list-style-type: none"> • Public: This rule can be used by anyone. Use this in a single-user system. • Private: This rule can only be used by the person who created it. Use this only in a multi-user system.
E	Description	Type the description of the rule, for clarity. (Optional)
F	Format	Shows the complete format of the rule you create. Automatically entered by Smart Alec as you complete the sections of the rule.

Item	Name	Description
G	Boolean operators	<p>Choose as appropriate from the following list:</p> <ul style="list-style-type: none"> • If • And • Or • Then • Else <p>The choice depends on what you want the rest of the row to do in relation to the other phrases.</p> <p>The first row always starts with "IF". Items F, G, H, and possibly J must be completed. The last row you use must always start with "THEN" or "ELSE" and end (Item I) with the command you want to be done when the entire statement is executed. A "THEN" statement can be used to activate a command to turn on a message and the "ELSE" statement can be used to activate a command to delete that message (when the conditions to turn on the message are not met.)</p> <p>You can have rows in between the first and last rows and these can start with either "AND" or "OR" to create additional conditions that must be met before the command will be done.</p>
H	Operand 1	From a list of date, day, time or existing variables, choose the variable to test by clicking <i>edit</i> to the left of this column for this phrase.
I	Operator	<p>Choose from the following list for comparing <i>Operand 1</i> with <i>Operand 2</i>:</p> <ul style="list-style-type: none"> • Is equal to (=) • Is not equal to (!=) • Is greater than (>) • Is greater than or equal to (>=) • Is less than (<) • Is less than or equal to (<=)
J	Operand 2	Specify the value to compare <i>Operand 1</i> to. Can be a variable or a literal value. (See Item K.)
K	Resulting display action	Choose the display command to be executed when all conditions are met. Make the choice from a list of existing display commands or groups of display commands by clicking <i>edit</i> to the left of this column for this phrase.
L	Variable/literal value switch	<p>Click as needed to set this as checked or unchecked. (Item G can not be "Then".)</p> <ul style="list-style-type: none"> • Checked: The choices for <i>Operand 2</i> consist of variables in a drop-down list. • Unchecked: You can type in your own specific value for <i>Operand 2</i>.

3. Click either *Add* or *Apply* for the *Add Display Command Rule* window.


Grouping notification devices

Notification Device Group Manager is used to designate logical groups of devices to facilitate sending a message to multiple notification devices simultaneously.

NOTE: Notification devices are created using *Notification Device Setup*. See “Identifying notification devices” on page 38.


Accessing Notification Device Group Manager

From the *System Use* group on the *SA Bar*, click once on *Notification Device Group Manager*.




Adding a Notification Device Group

1. Choose the button to add a new notification device group.



2. For this example, we will add a notification device group called “Front offices”, as shown here. See the table below for descriptions.



Item	Name	Description
A	Group name	Name of the notification device group as it will be known
B	Group Description	Description of the notification device group, for clarity (Optional)
C	Ownership	Specify who can access and use this notification device group. (Available only if activated by the administrator.) <ul style="list-style-type: none"> • Public: This group will be available to everyone. Use this in a single-user system. • Private: This group will be available only to the person who created it. Use this only in a multi-user system.
D	Notification Device	Choice of notification devices to be included in the group. The list on the left shows all available devices. The list on the right shows the devices to be included in the group.

3. **Specify a name for the group, in this case “Front offices”.**
4. **(Optional) Provide a description.**
5. **Designate ownership. (Available only if set on by the administrator.)**
6. **Choose any notification devices from the list on the left by clicking the device and then the arrows button or by double-clicking the device.**
7. **Choose either *Add* or *Apply*.**


Grouping display commands

Display Command Group Manager is used to designate logical groups of display commands. Then you can create another command to submit the command group. Doing this lets you essentially issue a series of commands all at once.

NOTE: Display commands are created using *Command Manager*. See “Using commands to control messages” on page 76.

Accessing Display Command Group Manager

From the *System Use* group on the *SA Bar*, click once on *Display Command Group Manager*.




Adding a Display Command Group

1. Choose the button to add a new display command group.



2. For this example, we will add a display command group called “Line counts”, as shown here. Click on either *Add* or *Apply*. See the table below for explanations.



Item	Name	Description
A	Group name	Name of the display command group as it will be known
B	Group Description	Description of the display command group, for clarity (Optional)
C	Ownership	Specify who can access and use this display command group. (Available only if activated by the administrator.) <ul style="list-style-type: none"> • Public: This group will be available to everyone. Use this in a single-user system. • Private: This group will be available only to the person who created it. Use this only in a multi-user system.
D	Display Command	Choice of display commands available to be included in the group. Click on any you wish to include. The list on the left shows all available display commands. The list on the right shows the display commands to be included in the group.

3. **Specify a name for the group, in this case “Line counts”.**
4. **(Optional) Provide a description.**
5. **Designate ownership. (Available only if set on by the administrator.)**
6. **Choose any display commands from the list by clicking the check boxes.**
7. **Choose either *Add* or *Apply*.**

Advanced functions

The functions in this section are those for which higher authority is needed (in a multi-user system) or which are seldom needed.

Higher authority is needed to create multi-user system-wide security authorization, using *System Administration*, *User Account Security Setup*, and *Application Security Setup*.


Seldom used are *Notification Device Interface Setup* and *Event Log Manager*.

System Administration

System Administration is used by the system administrator for system-wide or high-level settings.


Accessing the System Administration application

From the *Advanced* group on the *SA Bar*, click once on *System Administration*. A screen like the one shown below will appear.



Components of the System Administration window

The picture below is representative of the *System Administration* window. See the table below for explanations of the components.



Item	Name	Description
A	Administration Levels	Allows you to see security settings or to hide them from all screens. The system installation default is "hidden", for a single-user system. In this case, all users except "Alec" are set to level 50 for Update and Detail authorization for all applications. To change 50 to any other setting, set <i>Administration Levels</i> to "Shown" and make the changes in <i>User Account Security Setup</i> and/or <i>Application Security Setup</i> . This, in effect, creates a multi-user system. <i>Administration Levels</i> must be set to "Shown" for <i>Default Ownership</i> to be available.
B	Default Ownership	Sets a default for ownership of system resources (i.e., notification devices, variables, and commands). The actual setting for any resource for any user can be changed at any time. <ul style="list-style-type: none"> • Public: Resources will be available to everyone. Use this in a single-user system. You may also use this, if desired, in a multi-user system. • Private: Resources will be available only to the creator. Use this, if desired, only in a multi-user system.
C	Socket Handler	Sets the port number for the Socket Handler connection. The default number is 8150. If you wish, you can type a different port number. See "Importing external data using sockets" on page 64 for more information.
D	Variable Category Settings	Creates user-defined categories for variables (Optional.) See below.

Managing categories for Variables


To create a new category for variables:

1. Check “Use Variable Categories”.
2. Type the desired name in the box for a new category.
3. Click the *Add* button.
4. Click *OK* or make other changes.

To delete a category from the existing list:

1. Check “Use Variable Categories”.
2. Highlight the desired category in the existing list.
3. Click the *Delete* button.
4. Click *OK* or make other changes.

For more information about variables, see “Identifying variables” on page 42.



Security authorization


Security concepts

Smart Alec security is used to permit or deny access to applications, functions, and system resources in order to separate administrative and setup functions from general management functions.


Security is set up such that there are levels for authority from 1 (greatest authority) to 99 (least authority). That is, the lower the number, the more authority you have, up to the point of your being “number 1.”

The security level is set for each user to determine how much authority the user is granted to access applications, functions, and system resources. The security level is also set for each application/function and system resource to determine the minimum authority needed for a user to access them. If a user’s authorization level is greater than or equal to the minimum needed for that application/function or system resource, then access is granted to that user.


Example 1
User can access the
system resource



Example 2
User can access the system resource



Example 3
User can **not** access the system resource



Where security is used

The security system is used for:

- creating and using system resources (i.e., notification devices, variables, commands)
- using applications (programs to run, some of which can create, authorize, or change system resources)
- using application functions (view details, make updates)

Security system controls

Applications

- If you have enough “details” authorization to use an application, that application will appear in the *SA Bar* for you. You will be able to use that application and view details of any data in it.
- If you have enough “update” authorization for an application, that application will also appear in the *SA Bar* for you. You will be able to view details and, in addition, you will be able to make changes using that application.

Resources

- Some applications can create and manage system resources. If you have sufficient “details” authorization for a system resource, you will be able to view details of any system resource data.
- For system resource applications, if you have sufficient “update” authorization, you will be able to view details and, in addition, you will be able to make changes to system resources.

Data

- Some applications can create data that can be designated as public or private. Each user who creates data in one of these applications determines whether that data is to be available to other users (public) or to only himself (private) when anyone is using that application. Then when that application is to present data to any user, the application checks to see if the data requested is for public use or only for private use. If the user is the creator of the data or if the data is for public use, the data is displayed. Otherwise, it is not.

Processing

- Similar to data, processing (display) commands can be designated as public or private.

Given all the above points, it is possible to have authorization to access an application for a specific system resource and to create one of those system resources, but not have enough authorization to use that system resource. For example, you could be authorized to use *Notification Device Setup* to initialize a new notification device, but not be authorized in *Notification Device Group Manager* to group that new notification device with others.

Classes of users

While security is set up such that there are levels of authority from 1 (greatest authority) to 99 (least authority), it is easiest to work with just a few levels. A default level of 50 has been established for a general level user, while a default level of 5 has been established for an administrative level user. Any other levels are acceptable for customized users, but 25 and 75 might be good choices because they are easy to use.

See “Creating user environments” on page 102 for detailed instructions for setting up individual users.

General user: lower authorization, set by system administrator

The default authorizations for a general user are as follows. These authorizations give normal access for applications and system resources for routine management of the system. This is how all users are initially set up in Smart Alec for all applications and system resources. Notice that all authorization level values are the same and therefore, all users have the same system access.

Type of authorization	Scope of authorization	Authorization level
Application	Applications–full access	50
Application	Applications–details access	50
Processing	Commands	50
System resource	Notification Devices	50
System resource	Variables	50

Administrative user: greater authorization, set by system administrator

The default authorizations for an administrative user (such as “Alec”) are as follows. These authorizations give high-level administrative access to set up applications and system resources.

Type of authorization	Scope of authorization	Authorization level
Application	Applications–full access	5
Application	Applications–details access	5
Processing	Commands	5
System resource	Notification Devices	5
System resource	Variables	5

Custom user: uniquely set up as needed

Authorizations for a custom user vary according to an individual’s need to access applications and system resources. Great care must be taken when setting up custom user authorizations and matching them with the settings for applications and system resources. Otherwise, some users may be inadvertently denied access.

The following is an example of one possible way to create another class of user.

Type of authorization	Scope of authorization	Authorization level
Application	Applications–full access	75
Application	Applications–details access	25
Processing	Commands	50
System resource	Notification Devices	50
System resource	Variables	75

This example gives limited access to variables and to update (“full access”) applications, gives broad access to view details in applications, and gives normal access to commands and notification devices.

Setting minimum security levels for applications and system resources

Security levels authorized for users work together with security levels for applications and system resources. Authorization levels are set for each user for applications in general, as shown above. In addition, minimum authorization levels are set for each specific application. If a user's authorization range is greater than or equal to the minimum needed for an application, then access is granted to that user.

Normally, default authorization levels for both users and applications are set to 50. However, in the Smart Alec system with the custom user illustrated above, application security could be set up with these settings for the applications shown here:

Specific application	Minimum authorization level needed
Application Security Setup	5
User Account Security Setup	5
Notification Device Setup	50
Notification Device Group Manager	75
Variable Rule Manager	50

In this example, a high level of authority is needed to gain access to *Application Security Setup* and *User Account Security Setup*. The user in this example does not have that level of authority. So these applications would not appear in the *SA Bar* for him. But he does have sufficient authority for full (update) access to *Notification Device Group Manager* and for details (read) access to both *Notification Device Setup* and *Variable Rule Manager*. Therefore, he would be able to make updates in *Notification Device Group Manager*, and he would be able to see details but not make updates in *Notification Device Setup* and *Variable Rule Manager*.

See "Authorizing applications and application functions" on page 108 for detailed instructions.

Creating user environments


The Smart Alec system is designed so that it can be used by many different people in a company in different ways. The purpose of *User Account Security Setup* is to establish users and to assign levels of authorization to any user for applications, variables, commands, and notification devices. In other words, you decide if users can access a given resource (application, device, etc.) and what functions they can do with it.

In a single-user environment, you only need to establish who the users are. All users have the same access to all system resources, so there is minimal setup for users.

However, in a multi-user environment, some people may need to have different access to various applications. For example, an administrator will need to have full access to all applications, while regular users might have access to only a few applications that they use. The Smart Alec security system allows users who have sufficient access authorization for applications to create, update and delete users.

Accessing the User Account Security Setup application


From the *Advanced* group on the *SA Bar*, click once on *User Account Security Setup*. A screen like the one shown below will appear, listing any existing users.



Setting up a user

In the user security screen, each row shows all the security authorizations for a given user.

- Select a user by clicking to the left of the row once.
- Add a new user by clicking the *New User* button.
- View, duplicate, update, or delete the chosen user by using the buttons on the toolbar or from the drop-down *File* menu.
- You can also access the screen to update a user by double-clicking to the left of the row.



The Smart Alec system comes installed with a default user of “Alec” so you can access the system immediately as user “Alec”. “Alec” has no password assigned. You can keep the user as “Alec,” or you can change the name or authorization of this user as desired. However, be sure to create a new user with full access before changing or deleting “Alec”.

Default Authorizations

The default authorization for applications and system resources for user “Alec” is 5. These authorizations give high-level administrative access.

The default authorization for applications and system resources for any other user is 50. These authorizations give normal access. In a single-user environment, you should not change this setting.

For a conceptual understanding, see “Security authorization” on page 96.

Adding a user

To add a new user, do the following:

1. From the *File* menu, choose *New*, or click on this button:



2. Fill in the values as appropriate for the new user.

Item	Name	Description
A	User name	Name by which this user is known. This field is not case-sensitive.
B	Password	For security, a set of characters to be entered by the user when logging into the system. May be left blank, if desired, except that, to use the Socket Handler Setup (see page 64) there must be a password. This field is case-sensitive.
C	Application Authorizations and levels	System processors validate requests against the level authorized for the user. If the user's level of authorization is equal to or higher than that required, the request is processed. These are set to a default of 50. In a single-user environment, these should not be changed from 50. In a multi-user environment, these are normally set to either 5 (administrator) or 50 (general), but they can be set to any desired level.

NOTE: For better understanding, see “System security” on page 6 and “Security authorization” on page 96.

Authorizing user passwords

User-authorized password

You, as a user, can add or change your own password at the *Login screen*. If you change your own password, the system administrator will not be notified and will not have access to what your password is. If you forget your password, the administrator can only change it for you to a new password. You can then change it back to what you want it to be.

1. When logging into Smart Alec, click *Change Password*. (You do not need to supply a password on the main *Login* screen.)

2. If there was an existing password, you must type that on this next screen. Then type the new password, and retype it again exactly the same way. You can use a new password, as shown below, or you can use a blank password for *New Password*. Using a blank new password, in effect, deletes any old password.

3. Click *Change*.
4. You will next be logged into Smart Alec.

Administrator-authorized password

The administrator can add or change the password for a user.


1. From the *User Account Security Setup and Security* application, highlight the entire row for the user by clicking in the column to the left of that user.



2. From the *File* menu, choose *Update*, or click on this:



3. Click *New Password*.




4. Type in the new password. Regardless of what the old password was, the default password supplied is “smartalec”. You can use “smartalec” (as shown below,) you can use a different password, or you can use a blank password. Using a blank password here, in effect, deletes any old password. Then click *OK*.



The image shows a dialog box titled "New Password". It has a teal header bar. Below the header, there is a label "Password" followed by a text input field containing the text "smartalec". At the bottom right of the dialog, there are two buttons: "OK" and "Cancel".

5. Click *Update*.



The image shows a dialog box titled "Update User". It has a teal header bar. Below the header, there is a label "User Name" followed by the text "Sam". Below this, there are two sections: "Application Authorization" and "Authorization Levels". Each section contains two rows of settings, each with a label and a spinner control set to "50". The "Application Authorization" section has "Full Access" and "Details Access". The "Authorization Levels" section has "Notification Device", "Variable", and "Command". At the bottom of the dialog, there are three buttons: "Update", "New Password", and "Cancel". The "Update" button is circled in red.

Authorizing applications and application functions

The purpose of *Application Security Setup* is to designate what level of authorization is needed by users to access specific applications and the functions in each.

In a single-user environment, all users have the same access authority for all application categories and all functions for each application. This access authority is automatically preset to 50 for applications and application functions.

In a multi-user environment, the system administrator can set unique levels for the access authority required for each application. The level can be set for both “update” (make changes to data) and “details” (only view details of data) functions. If the level of authorization assigned to a user is equal to or greater than the level of authorization required for a given application, the user can access that function for that application. (Levels of authorization go from a low of 99 to a high of 1. A lower number gives higher authority.)

Understanding application functions

Update


A user with sufficient authorization for update application access can use all functions in any Smart Alec application for which he has authority. This is especially common in a single-user environment, where all authorization values are the same for all users, so all users can access all applications and all application functions.

Details

A user with sufficient authorization for details application access, but not enough to update applications, can only access the details function in any Smart Alec applications to which he has authority. This is especially common in a multi-user system configuration, where some users only need to view data in the Smart Alec system.

Accessing the Application Security Setup application

From the *Advanced* group on the SA Bar, click once on *Application Security Setup*. A screen like the one shown below will appear, listing existing settings.



Authorizing application security

The initial value for update and detail authorization levels is automatically preset to 50 for all users (except for the system-installed user “Alec”) and for all applications (except for the administrator applications: *System Administration*, *User Account Security Setup*, and *Application Security Setup*.)

In a single-user environment, the authorization level should remain at 50 for all new users.

To create a multi-user environment, the Smart Alec administrator can change either the update or detail values for any application (in *Application Security Setup*) or for a user’s security (in *User Account Security Setup*.) Doing this can block access to functions for these users.

The graphic below indicates the meaning of the *Application Security Setup* window.

Authorizing applications and application functions

Update button – allows you to view and change values.

Details button – allows you to view, but not to change, values in this application.

Update Value indicates the level of authorization a user needs in order to be able to change any values in that application.

Detail Value indicates the level of authorization a user needs in order to be able to view any values in that application. Without sufficient authority here, the user will not even be able to access the application.


Click in this column to select an application.

Application	Update Value	Detail Value
AppSecurity.exe	5	5
CommandManager.exe	50	50
DCGroup.exe	50	50
DDEInput.exe	50	50
DeviceInterface.exe	50	50
EventLogManager.exe	50	50
Message Manager.exe	50	50
NDGroup.exe	50	50
NotificationDeviceSetup.exe	50	50
OPCDataSourceSetup.exe	50	50
SAShutdown.exe	50	50
Security.exe	5	5
SystemAdministration.exe	5	5
VariableRuleManager.exe	50	50
VariableSetup.exe	50	50

Application	Application name
AppSecurity.exe	Application Security Setup
CommandManager.exe	Command Manager
DCGroup.exe	Display Command Group Manager
DDEInput.exe	DDE Data Source Setup
DeviceInterface.exe	Notification Device Interface Setup
EventLogManager.exe	Event Log Manager
Message Manager.exe	Message Manager
NDGroup.exe	Notification Device Group Manager
NotificationDeviceSetup.exe	Notification Device Setup
OPCDataSourceSetup.exe	OPC Data Source Setup
SAShutdown.exe	Smart Alec Shutdown
Security.exe	User Account Security Setup
SystemAdministration.exe	System Administration
VariableRuleManager.exe	Variable Rule Manager
VariableSetup.exe	Variable Setup

Authorization for each application can be changed individually as follows:

1. Highlight the application to change by clicking in the column to the left of that application. Then click *Update*.




NOTE

Remember, the lower numbers mean that more authority is needed to access the application.

2. Assign the values needed for a user to have authority to update and to view details. Then click either *Update* or *Apply*.

Update Value indicates the level of authorization a user needs in order to be able to change any values in that application.

Detail Value indicates the level of authorization a user needs in order to be able to view any values in that application. Without sufficient authority here, the user will not even be able to access (see) the application.




Use this drop-down arrow to select another application to view and change.

3. The following are suggested values for both update and details levels for a single-user environment and for a multi-user environment with an administrator and one or more general users.

System application name	Common application name	Values	
		Single-user environment	Multi-user environment
AppSecurity.exe	Application Security Setup	5	5
CommandManager.exe	Command Manager	50	50
DCGroup.exe	Display Command Group Manager	50	50
DDEInput.exe	DDE Data Source Setup	50	5
DeviceInterface.exe	Notification Device Interface Setup	50	5
EventLogManager.exe	Event Log Manager	50	5
Message Manager.exe	Message Manager	50	50
NDGroup.exe	Notification Device Group Manager	50	50
NotificationDeviceSetup.exe	Notification Device Setup	50	5
OPCDataSourceSetup.exe	OPC Data Source Setup	50	5
SAShutdown.exe	Smart Alec Shutdown	50	5
Security.exe	User Account Security Setup	5	5
SystemAdministration.exe	System Administration	5	5
VariableRuleManager.exe	Variable Rule Manager	50	50
VariableSetup.exe	Variable Setup	50	5

Viewing application authorization levels

1. Highlight the application by clicking in the column to the left of that application. Then click the *Details* button.




NOTE

Remember, the lower numbers mean that more authority is needed to access the application.

2. You can now see the values needed for a user to have authority to update and view details for this application. Then click *Close*. No changes will be saved.

Update Value indicates the level of authorization a user needs in order to be able to change any values in that application.

Detail Value indicates the level of authorization a user needs in order to be able to view any values in that application. Without sufficient authority here, the user will not even be able to access the application.



Use this drop-down arrow to select another application to view.

Identifying notification device interfaces


Notification Device Interface Setup is used to designate the type of hardware to be used for sending messages to notification devices. A notification device interface is normally set up the first time that a notification device needing it is initialized, but it also can be set up before a device is initialized, for instance, before the hardware is actually installed.

Types of notification device interfaces

There are several types of notification device interfaces. For descriptions, please see “Appendix 2: Types of Notification Device Interfaces” on page 124.


Accessing the Notification Device Interface Setup application

From the *Advanced* group on the *SA Bar*, click once on *Notification Device Interface Setup*. A screen like the one shown below will appear, listing any existing notification device interfaces.




Adding a notification device interface

1. Choose the correct button for the type of notification device interface you wish to add.



2. For this example, we will add a wide-area pager interface, as shown here. See the table below for explanations.

NOTE: A modem must be installed on this computer for a wide-area pager.



Item	Name	Description
A	Interface name	Name of the interface as it will be known.
B	Description	Description of the interface, for clarity. (Optional)
C	Modem name	Name of the modem used for the pager. At least one modem must already be installed. If only one modem is attached to this computer, its name is automatically chosen. Otherwise, choose the correct modem from the list.
D	Number to dial	Type the complete phone number to be dialed to access the paging service. This includes any external access code, international code, area code, number, and any other codes needed, for example, *70 to disable call waiting. You can use any character that is valid for your modem. A comma denotes a 2-second pause. Other characters such as spaces, parentheses, dashes and periods are acceptable for visual clarity, but are not required.
E	Baud rate	The speed of the modem used when sending to the pager. The default setting is 9600 baud., which is the baud rate that must be used with an ALPHA sign.
F	Com port	The COM port to which the modem is attached.
G	Packet size	The maximum number of bytes the pager can process at a time. The default is 175. (Contact your wide-area paging service if needed.)
H	Communications properties	Choose one of the available sets of properties for transmissions. The default setting of 8 bits, no parity, and one stop bit is recommended.
I	Advanced dialing properties...	Choose this button to set up the modem initialization string and the number of retries. This function is only for the wide-area pager interface.

3. For the dialing properties for this example, choose the correct settings for the wide-area pager interface. See the table below for explanations.



Item	Name	Description
A	Modem Initiation String	Initialization string to use for this modem. See the documentation for your modem for more information.
B	Number of retries	Number of times to attempt connection.

Settings for additional notification device interfaces

In addition to the wide-area pager illustrated above, here are settings for serial, email, local pager, and terminal server interfaces. Note that there is no modem interface.

Serial interface

Item	Name	Description
A	Interface name	Name of the interface as it will be known.
B	Description	Description of the interface, for clarity. (Optional)
C	Interface settings	For an ALPHA sign, the default settings of 9600 baud, 8 bits, no parity, and one stop bit are recommended. Specify <i>Com Port</i> as appropriate for your computer.

Email interface

Item	Name	Description
A	Interface name	Name of the interface as it will be known
B	Interface Description	Description of the interface, for clarity (Optional)
C	Email profile	Email identity to use. This is the default user of the computer, not necessarily the Smart Alec user name. See your system administrator if unsure.
D	Email password	Password that is valid in the network for the email profile. When an email interface is set up, there is an additional prompt to confirm the password. This password is only used for sending email through the network.

Local pager interface

Item	Name	Description
A	Interface Name	Name of the interface as it will be known.
B	Interface Description	Description of the interface, for clarity. (Optional)
C	Interface settings	Choose appropriate settings for this interface. To find these settings (except for Packet Size) click <i>Start > Settings > Control Panel > System</i> . Next, click the "Device Manager" tab and then <i>Ports</i> . Finally, double-click the <i>COM port</i> you need and then the "Port Settings" tab. The default settings of 9600 baud, 8 data bits, no parity, and one stop bit are recommended.
D	Packet Size	The maximum number of bytes the pager can process at a time. The default is 175. For details, refer to the documentation for the pager or contact your network system administrator.

Terminal server interface


Item	Name	Description
A	Interface Name	Name of the interface as it will be known.
B	Interface Description	Description of the interface, for clarity. (Optional)
C	IP Address	The four-node Internet Protocol address of the terminal server, for example: 192.40.13.10. Consult your network system administrator if needed.

Managing the log of Smart Alec system events

For system support purposes, Smart Alec monitors and creates a log of all events that occur within the system. This log is available to view by using the *Event Log Manager*.

Accessing the Event Log Manager

From the *Advanced* group on the *SA Bar*, click once on *Event Log Manager*. A screen like the one shown below will appear. See the table below for descriptions.




Item	Name	Description
A	Write to file	Create a tab-delimited print (.prn) file with user-selected fields from the database.
B	Delete	Delete selected event(s).
C	Archive	Save the entire database as a text (.txt) file.


Item	Name	Description
D	Filter	Select only events that fit specific criteria (data/time and/or database field).
E	Sort Ascending	Sort A to Z or 0 to 9.
F	Sort Descending	Sort Z to A or 9 to 0.
G	Search	After selecting a column, use this to search for a specific value.
H	Value to search for	Enter the value to find.

Options for viewing the event log database in the Event Log Manager

- *Write to a file:* Create a tab-delimited print (.prn) file with user-selected fields from the database.



- *Filter:* Select only events that fit specific criteria (date/time and/or one or more database fields)




- *Refresh* (from *Edit* menu): Update the list of events



- *Invert selection* (from *Edit* menu): Select only those records not already selected.



- *Sort*: Sort high-to-low or low-to high.



Options for managing the event log database

- *Select all*: From the *Edit* menu, choose *Select All* to highlight all records. This allows you to then delete all records at one time.
- *Select some records*: To select specific records, you can click on one and then shift-click or control-click on more. This allows you to delete individual records.
- *Deleting records*: With records selected as above, press the **Delete** key. You will be prompted to confirm the deletion.
- *Control database size*: From the *Tools* menu, choose *Preferences* to set preferences to limit the number of events listed in the database to a specific threshold number, to overwrite the oldest records (never, as needed, or after x number of days), and to state the wording of the warning

message when the number of events in the database has reached the limit.



Appendices

Appendix 1: Smart Alec computer requirements

Make sure your computer system fits these minimum requirements:

- Personal computer, IBM or compatible
- Pentium 200 MHz processor, minimum
- Microsoft NT Workstation 4.0 (strongly recommended), or
*Microsoft Windows 98, or
Microsoft Windows 95*
- 64 MB RAM
- 25 MB hard disk storage space
- SVGA 800 x 600 color monitor
- Mouse
- CD-ROM drive

Appendix 2: Types of Notification Device Interfaces

The Smart Alec system includes the following notification device interfaces. For specific networking information, refer to **Network Configurations**, PN 9708-8046.


NOTE: You may have purchased notification devices from other third party sources. Hardware support for these devices is not provided by Adaptive Micro Systems. You will need to consult the third party source for any needed technical support.

Serial interface

A serial notification device interface uses cables to directly connect ALPHA SA signs to a computer, and messages are sent over this cabling.

A serial interface works best when all the notification devices are in one building.

PC – sign – sign – sign – etc.



Wide area pager interface

A wide area pager notification device interface uses a modem attached to your computer and a wireless receiver attached to a remote notification device, either a display or a pager. Basically, when a message is sent, it is transmitted to the remote notification device when the computer modem calls the device's modem. Specifically, a message is sent from your computer to the attached modem. The modem then dials a paging service, such as SkyTel, and this paging service actually transmits the message to the wireless receiver.

A modem connection is often used for devices that are not in the same building and possibly not in the same city. It works best when message data does not change rapidly.


Modemtr Ta
Modem

PC with Smart Alec software

Terminal server interface

A terminal server notification device interface uses a Local Area Network cabling system to transmit messages to a device with an IP address on the LAN. (For specific information about Alpha Ethernet Adapters, refer to **Networking ALPHA signs with ALPHA Ethernet Adapters**, PN 9708-8093.)

PC – LAN network – terminal server box – sign – sign – sign – etc.



Appendix 3: Understanding modes on signs

Modes are special effects used to change the way a message appears on a sign.

Table 2: How modes function

Mode	Function
Automode	This is the default mode, which actually consists of using all other modes available to each sign. If no other mode is selected, the message will appear in Automode.
Flash	All characters flash off and on from the point of flash mode until the point where another mode is selected, if any.
Hold	Holds the message or specified text in a fixed place for several seconds.
Interlock	Alternating rows of dots enter from each direction of a sign and interlock to form the message in the center of the sign.
Roll	Rolls the characters in the message in their entirety onto the sign in the desired direction. You can choose to roll up, down, left, right, in, or out.
Rotate	Rotates a message from right to left across the sign without stopping. For certain signs, text can be condensed or standard.
Scroll Up	Moves the message one line at a time from bottom to top of the sign. The previous line is pushed off the sign.
Slide	The message moves onto the sign from one direction to the other, one character at a time.
Snow	The dots of each character in the message fall randomly onto the sign as if it's snowing.
Sparkle	The message sparkles onto the sign by randomly filling the letters of the message (at the start of the message display only.)
Spray	The message is sprayed onto and across the sign, left to right, column-by-column and character-by-character.
Starburst	Random starbursts explode over and around letters of the message on the sign.
Switch	Alternating characters of the message slide onto the sign from different directions, that is, the first character slides up, the next down, etc.
Twinkle	The message appears in its entirety in a twinkling effect with lights flickering off and on for the duration of the message display.
Wipe	The message is wiped onto the sign in the direction specified, filling in each of the characters row-by-row or column-by-column. It looks as if it's washing over the old message. You can choose to roll up, down, left, right, in, or out.

Table 3: Modes available on signs

Sign (FM = Full Matrix, CM = Character Matrix, LM = Line Matrix)		Modes																	
ALPHA sign	Type	Automode	Flash	Hold	Interlock	Roll	Rotate		Scroll	Slide	Cycle color	Snow	Sparkle	Spray	Starburst	Switch	Switch half the display	Twinkle	Wipe
							Standard	Condensed											
Series 200	FM	●	●	●	●	●	●	●	●	●		●	●	●	●	●		●	●
Alpha 220C	FM	●	●	●	●	●	●	●	●		●	●	●	●	●	●	●	●	●
Series 300	FM	●	●	●	●	●	●	●	●	●		●	●	●	●	●		●	●
Series 400	FM	●	●	●	●	●	●	●	●		●	●	●	●	●	●	●	●	●
Series 4000	FM	●	●	●	●	●	●		●	●		●	●	●	●	●		●	●
Series 7000	FM	●	●	●	●	●	●	●	●	●		●	●	●	●	●	●	●	●
Big Dot	FM	●	●	●	●	●	●	●	●	●		●	●	●	●	●		●	●
Alphavision FM	FM	●	●	●	●	●	●		●				●					●	●
Alphavision CM	CM	●	●	●															●
790i	FM	●	●	●	●	●	●		●	●		●	●	●	●	●		●	●
Solar	FM	●	●	●	●	●	●		●				●					●	●
Director	CM	●	●	●															●
2.1-inch CM	CM	●	●	●															●
3.2-inch CM	CM	●	●	●															●
PPD	LM	●	●	●	●	●	●		●	●		●	●	●	●	●		●	●

Appendix 4: Understanding line positions (Top, Middle, Bottom, Fill)

Line positions on signs

The “line position” refers to where a message can be displayed on a sign — the top, middle, bottom, or fill positions. Line position are available with most modes, e.g., Hold, Snow, Sparkle, etc. While the way these work varies slightly on different types of signs, the basic concept is shown in the pictures here.

Line position	What appears in the Message Manager:	What is displayed on a 2-line sign:
Top	[Top;Hold]Las Vegas \$85, Chicago \$199, New York \$235	
Middle	[Middle;Hold]Las Vegas \$85, Chicago \$199, New York \$235	
Bottom	[Bottom;Hold]Las Vegas \$85, Chicago \$199, New York \$235	
Fill	[Fill;Hold]Las Vegas \$85, Chicago \$199, New York \$235	

Types of signs

Signs are categorized by number of lines of text.

1. Single-line (BETAbrite 215R & 215C, 220, 300 series, 400 series, Big Dot)
These signs are of varying lengths but are always 7 dots high.
2. Double-line (4000 series)
These signs are of varying lengths but are always 16 dots high.
3. Triple-line (7000 series) and Multiple-line full matrix (Alphavision)
These signs are of varying heights and widths.
4. Multiple-line character matrix (AlphaVision, Director)
These signs are of varying heights and widths, but have character blocks with spaces between.

Single-line (BETAbrite 215R & 215C, 220, 300 series, 400 series, Big Dot)

On a single-line sign, all characters line up at the bottom of the sign and work their way up for as many dots as the font supports.

Example:



Exception conditions:

- If the sign receives a font that is larger than the sign can display, it will “size it down”.
 - 7-high normal characters are substituted for any 15-high normal characters.
 - 7-high fancy characters are substituted for any 15-high fancy characters received, etc.
- If a graphic (picture) is received that is taller than the display can show, the top seven rows are displayed.
- If a graphic is received that is wider than the display can show, it will show the left-most columns of the picture.
- If a graphic is received that is smaller than seven dots tall, it will be displayed from the bottom of the sign working up, similar to the 5-dot character set shown above.
- If a character set is not established in the message, 7-high normal characters are used.
- If top, bottom, or fill positions are received, middle is used.

Double-line (4000 series)

Top position

On a double-line sign, the top position is defined as the top 7 dots of the sign, and operates in the same manner as a one-line sign. See exception conditions for a single-line 7-row sign.

Bottom position

The bottom position is defined as the bottom 7 dots of the sign, and it also is treated as a one-line sign. See exception conditions for a for a single-line 7-row sign.

Middle position

The middle position is treated as though it was one line of 16 dots. Each line of text presented on that line is prescanned to determine the largest piece of text (or graphic object) to be displayed. The line of text is then vertically centered based on that largest object. For example, if you have a line of text which has mostly 5-high characters, but has one 10-high character, the line is viewed as a 10-row high line, and since this is a 16-row sign, that leaves 6 extra rows... 3 blank rows on the top and 3 blank rows on the bottom. All text and objects are then lined up to this new virtual bottom (the 13th line) and treated the same as in a single-line sign.

Exception conditions:

- If the sign receives a font that is larger than the sign can display, it will “size it down”.
On this sign, in the middle position, the only characters that are too large would be characters using the “double-high” control code. This control code is ignored.
- If a graphic is received that is taller than the display can show, the top sixteen rows are displayed.
- If a graphic is received that is wider than the display can show, it will show the left-most columns of the picture.
- If a character set is not established in the message, 16-high normal characters are used.

Fill position

On a 4000 series sign, the fill position indicates that you wish to use no more than 7-high characters, and that you want to fit as much text on the screen as you can. When in this mode, the sign views itself as having two lines of 7-high characters, and no means of doing a character set larger than 7-high. If a graphic is selected, at

most seven rows of that graphic will be displayed. If the last piece of text to be displayed (towards the end of the message) is only one line worth of text, the sign will place 4 blank rows of dots at the top and the bottom of the text in order to center the last line of text vertically.

If the sign is operating on the top row, the bottom of that row is assumed to be the 7th row of dots. All text is started from there and worked up. (5-row characters will use rows 3 – 7, while 7-row characters will use rows 1 – 7.)

If the sign is operating on the bottom row, it works its way up from row 16. (5-row characters will use rows 12 – 16, while 7-row characters will use rows 10 – 16.)

Exception conditions:

- If the sign receives top, bottom, or fill modes and also a font that is larger than 7-high, it will “size it down”:
 - 7-high normal characters are substituted for any 15-high normal characters.
 - 7-high fancy characters are substituted for any 15-high fancy characters received, etc.
- If a graphic is received that is larger taller than 7 rows high (15-high for middle mode), the top 7 rows (top 15 for middle mode) are displayed.
- If a graphic is received that is longer than the display can show, it will show the left-most columns of the picture.
- If a character set is not established in the message, 7-high normal characters are used.

Triple-line (7000 series) and Alphavision Full Matrix

Top/Bottom

These two positions work in tandem with each other. There is an imaginary line between the top half and the bottom half to the display. We will call this line the centerline. In the example below, the “Centerline” is between the “HELLO”, and the “lots of text about basically”. The centerline divides what is used on the

sign for top position commands from what is used for bottom.



Establishing the position of the centerline

The centerline position is typically established by the first top command received, and the rest of the space is used for the bottom. If the bottom command comes first, the centerline is placed at its highest possible position, row 8, allowing for one line of 7-dot characters on the top. If the top command comes first, and not a bottom, the centerline's position is determined by the amount of text following the position command.

Examples:

- If one 7-dot high line of text is received (following a top command), the centerline will be fixed at row 8.
- If one line of 10-dot characters is received (following a top command), the centerline will be placed at position 11.
- If two lines of 5-dot high characters are received (following a top command), the centerline is placed at row 12 (5 for each line of text, plus the 2 blank rows between the lines.)

Two exceptions to the above rules are as follows:

1. The centerline is never placed higher than 8 rows from the top of the sign.
2. The centerline is never placed lower than 8 rows from the bottom of the sign.

Note: This ensures that there is always room for one line of 7-dot high characters on the top or bottom (including one blank row.)

Once its position is established, the centerline remains fixed at that position until a fill or middle position command is received. All subsequent top or bottom position commands use the amount of space set

by the position of the centerline. You cannot change the position of the centerline with a second top/bottom command.

Example:

Message = [Top;Hold][Green][SS5][Bottom;Hold]lots of text about basically nothing



Middle position

The middle position is treated as though it were one line as many dots high as the sign is tall. Each line of text presented on that line is prescanned to determine the largest piece of text (or graphic object) to be displayed. The line of text is then vertically centered based on that largest object. For example, if you have a line of text which has mostly 5-high characters, but has one 10-high character, the line is viewed as a 10-row high line. Assuming this is a 24-row sign, that would leave 14 extra rows...7 blanks on the top and 7 blank rows on the bottom. All text and objects are then lined up to this new virtual bottom (the 21st line) and treated the same as in a single line sign.

Exception conditions:

- If a graphic (picture) is received that is larger than what the display can show, the top-most rows are displayed.
- If a graphic (picture) is received that is longer than the display can show, it will show the left most columns of the picture.
- If a character set is not established in the message, 7-high normal characters are used.

Fill position

On a 7000 series or Alphavision sign, the fill position indicates that you wish to fit as much text on the screen as you can. On these signs as opposed to the 4000 series, you can select character sets larger than 7-high in the fill

mode. The sign will start from the top of the screen working down. If you select a 15-row character set, the sign will fit as many 15-row lines of text on the screen as possible. As soon as the sign detects that the next line will not fit, it will stop creating the current page and display it. The next page will begin with the line that would not have fit. If the text does not use up the entire display, the sign will center the text vertically, splitting the blank space between the top and the bottom.

Exception conditions:

- If a graphic is received that is taller than seven rows high, the top seven rows are displayed.
- If a graphic is received that is wider than the display can show, it will show the left-most columns of the picture.
- If a graphic is received that is smaller than seven dots tall, it will be displayed from the bottom of the sign working up...similar to the 5 dot character set explained above.
- If a character set is not established in the message, 7-high normal characters are used.

Alphavision Character Matrix

This sign works exactly like the Triple-line (7000 series) and Alphavision Full Matrix signs, with the following exceptions.

Exception conditions:

- If a mode other than a “Wipe” mode is received, it is replaced with “Hold”.
- An Alphavision sign ignores any of the following:
 - graphics
 - any character set command except 5- and 7-high normal
 - wide
 - double-wide
 - double-high
 - true descenders

Appendix 4: Understanding line positions (Top, Middle, Bottom, Fill)

- proportional spacing
- animations
- If a character set is not established in the message, 7-high normal characters are used.

Appendix 5: Including graphics in Smart Alec messages

Graphics can be included in a message, as well as text and variables.

1. Create the necessary graphics, if not already created. Store them all in the same folder.
 - The graphics must be in bitmap (.bmp) format.
 - The graphics must be 256 colors or less. “True color” is not valid.
 - Set the number of pixels (x by y) equal to the sign size or less.
 - Neither black nor white in a graphic show up on the sign.
 - Other colors in the graphic are approximated by the sign as closely as possible using the sign’s colors.
2. In *Microsoft Access*, open SmartAlec.mdb.
3. In the database, open the TB_Global_Init table.
4. For “PathToGraphics”, specify the full path where the graphics files are saved, ending the path name with a forward slash (\). Save and close this table.
5. Still in *Microsoft Access* and SmartAlec.mdb, open the TB_graphic table.
6. Specify the graphic files to be used.
 - Specify name and description as desired.
 - For the Filename, specify the complete name of the graphic, including the extension but not the full pathname.
7. Save and close the TB_graphic table and SmartAlec.mdb.
8. Open Smart Alec. If Smart Alec was open before setting the PathToGraphics, restart Smart Alec so the new path in Step 4 will be registered correctly.
9. Open the Message Editor and choose a new or existing message.

- Enter any desired text.
 - Specify the graphic to display, using this format: {11,1}
 - The “11” indicates that it’s a graphic to be included and the “1” is the graphic ID number as seen in the TB_graphic table. These ID numbers are automatically generated and remain static for the life of the record in this table.
10. Save the message.
 11. (Optional) Check the syntax of the message:
Tools > Message Syntax Check.

If a message with a graphic included is running and then the graphic is changed, the graphic in the current message will not change. To use the changed graphic, send a command to delete the original message. Then either 1) create a new message including the changed graphic and send a new display command for the new message; or 2) select the original command with the original message and choose File > Schedule Activities, reset the schedule, and send this command for the original message.

Appendix 6: Socket Interface

API Process Guide

Purpose

The purpose of this appendix is to serve as a guide for a developer writing software to interface with Smart Alec through the Socket Input Handler.

Definitions

- **ASCII:** American Standard Code for Information Interchange – A set of values corresponding to numbers, letters, symbols and codes for exchanging information. Used in computing to send data across various lines of transmission.
- **Null terminated string:** A series of ASCII characters ending with a byte valued at 0. This is similar to the standard implementation of a C++ character string class.

Theory of Operation

The Socket Input Handler acts as a direct interface into the system. It handles a Data Source Variable change of state (COS) process.

You connect to the socket handler using a standard socket implementation for any computer platform and the Port number found in the main Smart Alec database. If the address and port are correct and the socket handler is running on the host computer, the handler accepts the connection. The system supports unlimited users (from different or the same IP Address), as the host computer's resources permit.

Login Sequence

1. Initiate a standard socket connection with the host computer using the IP Address of the host computer and the port number found in the Smart Alec database.
2. The Smart Alec Socket Input Handler accepts the connection and logs the IP address of the client system.
3. The client sends a 'Login Packet' described later in this document.
4. The Socket Input Handler verifies the login name and password with the database entries to determine if the client is a valid user.
5. If the user login is not valid, the Socket Input Handler sends an 'Error Packet' containing a message to that effect back to the client system. It then immediately terminates the connection.
6. If the user login is valid, a 'Success Packet' is returned to the client and operation continues as normal.

Standard Operation

After a successful connection has been established, a valid user login has occurred and a 'Success Packet' has been returned, the Socket Input Handler sits in an idle state waiting for new packets to come in.

At that point, new packets can enter the system at any time. A packet is introduced into the system by sending data serially across the socket connection. The elements of the packet are explained further below, but the basic ordering is as follows:

- Class
- Subclass
- Message ID
- Priority
- Set of arguments

After the packet has entered the system, the Socket Input Handler parses the packet header for information

Description: Specific identifier for the type of message packet

Name: Message ID

Type: long int (32 bits)

Description: Used by client system to identify a message. Upon response, the Message ID will be identical to the ID of the packet being responded to.

Name: Priority

Type: short int (16 bits)

Description: Used internally by Smart Alec for routing priority. This feature is not currently implemented. Send a short int with a value of 0.

Name: Arguments

Type: Set of null terminated ('\0') ASCII character strings. All ASCII characters are valid except ASCII 0 ('\0').

Description: A set of null terminated strings of data. The strings are sent sequentially with only the null terminator in between. Each class and subclass has its own packet definition for number of strings to send and rules for format.

Data Source Variable COS

Description

This type of packet alters the value of a variable already existing in the Smart Alec system. Typically, this is used to update a variable on a display device, give notice of an event, or display general information.

Packet Definition

Class: 8

SubClass: 8

Arguments: 2 arguments are expected for this type of message packet

Name: Var_Name

Limits: 32 characters

Description: Name of the variable as identified in the database

Name: Var_Cur

Limits: 128 characters

Description: Updated value of the variable (in null terminated string format)

Login Packet

Description

This is the first packet that needs to be sent into the system. If the login values do not match up with a user in the Smart Alec system, the Socket Input Handler returns an 'Error Packet' indicating an invalid login and the connection will be terminated. If this is not the first packet sent, an 'Error Packet' is returned indicating that the user is not logged in yet and the session will be terminated. If a second login is attempted after a successful login has already occurred on this connection, an 'Error Packet' is returned indicating that the user is already logged in and the session continues.

Packet Definition:

Class: 1

SubClass: 1

Arguments: 3 arguments are expected for this type of message packet

Name: User_Name

Limits: 64 characters

Description: The name used to identify the account of a Smart Alec user

Name: User_Password
 Limits: 255 characters
 Description: The password for this Smart Alec user account

Name: Callback_Port
 Limits: Between 1024 and 65535 (in ASCII characters)
 Description: The number of a port on the client's system that has a listen connection open in the event of outstanding notifications after a broken connection. In this case, the socket handler opens a socket to that port on the client's system. This feature is not currently implemented. Send a null terminated string containing the number 0 (i.e., '0' or ASCII 40.)

Log Message

Description

This type of packet is primarily used as a diagnostic or debugging tool. It places a message or note directly into the Smart Alec Event Log, the Socket Input Handler local log file, and the Smart Alec Trace System.

Packet Definition

Class: 0
SubClass: 0

Arguments: 1 argument is expected for this type of message packet

Name: Message
 Limits: 64 characters
 Description: A message or note to place directly into the Smart Alec event log, the Socket Input Handler local log, and the Smart

Alec event trace system. Smart Alec logs this message regardless of whether logging or tracing is enabled.

Socket Command

Description

This type of packet is used to issue a command directly to the Socket Input Handler. The scope of these commands is limited, but can prove to be useful. The tools currently available are based on dynamically controlling tracing and logging.

Packet Definition

Class: 0

SubClass: 1

Arguments: 1 argument is expected for this type of message packet

Name: Command

Limits: 32 characters (Case Insensitive)

Description: A control command to be issued directly to the Socket Input Handler

Available commands:

- None

Return Packets

These packets are returned upon completion of the processing of a submitted packet by the Socket Input Handler. The packet format is the same as with packets sent into the socket handler. The Message ID that comes back in this packet is the same ID that was sent in the original packet.

Success Packet

Description

The success packet is a return packet used in the synchronous transport protocol to indicate that a packet entered into the system has been processed by the socket handler and routed to its proper destination. After

receiving this packet, the client system is safe to send another packet.

Packet Definition

Class: 0

SubClass: 2

Arguments: 1 argument is expected for this type of message packet

Name: Success Message

Limits: 32 characters

Description: A string indicating that processing is complete for a client's message

Error Packet

Description

The error packet is returned when a problem has occurred either with the incoming packet or within the Socket Input Handler application. The argument within the packet gives information on the nature of the error. It is recommended that the client system examine the nature of the error and make a determination whether it should continue sending data.

Packet Definition

Class: 0

SubClass: 3

Arguments: 1 argument is expected for this type of message packet

Name: Success Message

Limits: 32 characters

Description: A string indicating nature of the error that the Socket Input Handler encountered with this packet. These errors are explained in the "Return Information Reference" below.

Return Information Reference

Login Errors

“Login Error - (<Msg ID>) User <Username> not found in system.”

Cause

1. The user has sent a login packet with a username not in the system.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system automatically boots the user by closing the socket connection.

Corrective Action

1. Reconnect and send a valid login name.
2. Check the Smart Alec program for registered users.

“Login Error - (<Msg ID>) User <Username> entered an invalid password.”

Cause

1. The user has sent a login packet with a username not in the system.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system automatically boots the user by closing the socket connection.

Corrective Action

1. Reconnect and send the right password.

“Login Error - (<Msg ID>) User <Username> chose an invalid port number: <Port>.”(Not currently being used)

Cause

1. The user has sent a login packet with a port number outside the valid range.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system automatically boots the user by closing the socket connection.

Corrective Action

1. Reconnect and send a valid port (1024 - 65535)

“No User Logged In - Closing Connection”

Cause

1. The user has tried to send a packet other than a login packet into the system before the user has logged in.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system boots the user by closing the socket connection.

Corrective Action

1. Log back into the system and make sure to send a login packet first.

“User <Username> is already Logged In”

Cause

1. The user is trying to send a login packet after a valid login.

System Response

1. Sends a message to the trace and log with the text above.

2. Sends an error packet back to the user with the text above.
3. The system continues normal operation.

Corrective Action

1. No corrective action is necessary. Just don't send any more login packets.

Data Errors

“Data Error - (<Msg ID>) Class <Class>,<Subclass> is not a valid packet type”

Cause

1. The user has sent a packet with an unrecognized class and subclass.

System Response

1. Sends a message to the trace with the text above
2. Sends an error packet back to the user with the text above.
3. The system discards the packet and flushes message queue.

Corrective Action

1. Make sure the user is sending packets that are known by the system.
2. Check the SA version to make sure that type of packet is supported.

“Data Error - (<Msg ID>) Class <Class>,<Subclass> Argument: <# of Arg> is out of range. Size = <Size of Arg>”

Cause

1. The user has sent a packet with data elements out of the domain set by the API.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system discards the packet and flushes message queue.

Corrective Action

1. Check the data to see if the user application is sending packets out of range.
2. Change the data to conform to the API guidelines.

“Data Error - (<Msg ID>) Class <Class>,<Subclass> Argument <# of Arg> has no value”

Cause

1. The user has sent a packet with data elements having size 0.

System Response

1. Sends a message to the trace and log with the text above.
2. Sends an error packet back to the user with the text above.
3. The system discards the packet and flushes the message queue.

Corrective Action

1. Check the data to see if the user application is sending packets with 0 size element.
2. Change the data to conform to the API guidelines.

Appendix 7: Troubleshooting

Questions and Answers

Q1. *How can I tell what messages should be running?*

A. The *Command Manager* lists all the commands that are set up. In the list, each command that is currently scheduled has a start time and end time. If there is no start time or end time, it means that the command, and thus the message, is shouldn't be running. Recurring commands always have a start and end time, even if that time period does not include the current time. Note that you may need to update the list of commands by choosing Update for a command which shows an end time earlier than the current time. Or you can close the *Command Manager* and reopen it.

Q2. *Why isn't my message showing up?*

A. There could be several reasons:

- There may be no command to add the message for the notification device.
- If a variable is supposed to trigger the message, be sure that there is a rule for the variable, set in *Variable Rule Manager*.
- The address might not be correct for that notification device. (See "Adding a notification device: ALPHA, pager, email" on page 39.)
- The sign might not have Smart Alec firmware.
- The RS232/RS485 jumper for a 4000 or 7000 series sign might not be set correctly. (See the **Network Configurations** manual, PN 9708-8046.)

A. Double-check to make sure everything is set up correctly. You can use the "Flowchart for setting up and using Smart Alec" on page 11 as a guide.

Q3. *Why aren't variables in my messages showing up?*

A. Be sure there is a source for the data: DDE, OPC, or sockets. See "Establishing DDE input data sources" on page 47, "Establishing OPC input data sources" on page 54, or "Importing external data using sockets" on page 64.

A. A DDE, OPC, or socket server may not be running or the link may not be correctly set up. Check the server and the physical connections to it.

Q4. *Why aren't the variables in my messages getting updated even though they showed up in the message when it started?*

A. Most likely, the DDE or OPC server is no longer running. Check the server and the physical connections to it. However, the variable should still be displayed with the default value.

Q5. *What happens if the DDE or OPC source is already running before Smart Alec starts?*

A. This is not a problem. Smart Alec is able to access the data correctly.

Q6. *I deleted a variable and now the Smart Alec system is running very slowly. Why might this be?*

A. The variable may have been supplied with data by an OPC data source. If so, you also need to delete that link in *OPC Data Source Setup*. (This is not a problem if the data is supplied by a DDE data source.)

Q7. *It doesn't seem as if messages are getting sent to notification devices. What can I do?*

A. Under any of the following conditions, you must shut down the Smart Alec system and then restart it before you can use the change:

- After adding a notification device
- After adding a notification device interface
- After losing a connection to a device
- After adding a DDE or OPC input data source

You should not need to shut down and restart Smart Alec under these conditions:

- Adding or changing a variable
- Adding or changing a message
- After losing a connection to a DDE input data source

A. Even if you did not recently add a component listed above, try *Start > Programs > Smart Alec* again. You do not need to shut down Smart Alec before doing this. If any Smart Alec background processing applications were not running for any reason, this will re-start:

- SBar.exe (the primary user interface)
- SAevtmgr.exe (the background event manager)
- Sockhandler.exe (the background socket data manager)
- Saopcsv.exe (the background OPC data manager)
- DDEInputHandler.exe (the background DDE data manager) If this does not run, it may be that the external data source is not running before starting Smart Alec. Start the external data source and then start Smart Alec.
- Ez95dm (the data manager for data in messages to signs)
- Ez95sv (the server for messages to signs)
- Alphaout (converts messages that people can read into a format that the notification device can use)
- Actsrvr (the manager for all activities)

(In *Windows*, you can see which programs are running by pressing **Ctrl/Alt/Del** together one time. Be sure to choose *Cancel* here rather than *End Task* or *Shut Down*.)


- Q8. *How can I be sure that a pager notification device is set up as alphanumeric?*
A. All pager devices are assumed to be alphanumeric.

Hardware diagnostics

When adding signs to a network of signs in the Smart Alec system, you can perform a test to determine if a new sign is correctly connected. The *Hardware Diagnostics* program allows instant verification that the network is set up correctly and a sign is connected correctly.

Signs can be attached to the network at any time, which means that a sign can be connected to the network while *Hardware Diagnostics* is running, and the sign will respond to the tests within seconds.


1. In Explorer, run **HW Diag.exe**, which is found on the original Smart Alec CD in a directory called Support.




2. Select the correct COM port for your computer and select **Alpha SA**. Then click *Start*.



3. The application will send out test messages to every sign on the network, that is, signs with addresses 1 through 255. It starts with message 0 (zero) and goes to message 999 and then repeats the cycle as long as it is running or until the *Stop* button is clicked.



4. At the end of each message test, the status indicates the test is complete.



5. To stop the testing, click the *Stop* button or close the program.

Where to go for additional help

If you need assistance, please follow this procedure:

1. Refer to relevant topics in this manual.
2. Refer to online Help for the specific application.
3. Contact your authorized Smart Alec distributor.

What you need to provide when you need assistance

If you need technical assistance, you will need to provide:

- full description of the problem
- the sequence of steps that lead up to the problem
- computer system hardware and relevant software application version numbers
- the version number of Smart Alec found in the splash screen when Smart Alec starts and also found in the *About* screen from the *Help* menu of any Smart Alec application.
- the product serial number – found on the outside packaging and on the registration card
- the version number of any relevant Smart Alec application, found by right-clicking on the application in Explorer, choosing *Properties* then clicking on the “Version” tab and also found in the *About* screen from the *Help* menu of the application.

Appendix 8: Glossary

Administrator	<p>Normally the applications that are needed to set up the Smart Alec system are available only to an administrator, while the applications needed for routine management of messaging needs are available to all users. In an environment where only one person is responsible for using Smart Alec, this user is also the administrator, with full access to all applications.</p> <p>Security is available so that, for instance, applications needed only by the Smart Alec administrator (to set up the system) are not accessible by normal users (for general management of the system.)</p>
Application	<p>A software program which a user can see and use to create, authorize, or change data. An application can be accessed from a menu or a toolbar.</p>
Authority	<p>Indicates the level of rights given to a user.</p>
Authorization, details	<p>Provides the capability to read (view), but not to change, the information about a subject.</p>
Authorization, update	<p>Provides the full capability to read (view) and also change the information about a subject.</p>
Command	<p>A way for a user to communicate a request for a desired physical action at a notification device. A command consists of message content, notification device destination, and running priority. It is formatted according to what is needed for each particular notification device.</p> <p>A command can, but does not always, trigger action, depending on priorities and prerequisite conditions. Pre-set variable display command rules can control when commands are processed, or commands can be scheduled by date/time.</p>
Data, private	<p>Data that is made available to only one individual user: the creator.</p>

Data, public	Data that is made available to all users.
Dead band	The smallest percentage of change necessary for variables to be sent to Smart Alec by the OPC server. Similar to delta value, but is expressed as a percentage, applies to the OPC server and to all numeric variables in the Smart Alec group.
Delta value	The number that is used to set a “plus or minus” range for the value of a variable. The value of the variable is compared with this range. If the value of the variable is outside the range (higher or lower), then that value of the variable is used to update the variable wherever the variable is used for a command. Otherwise, the value of the variable is not updated.
Destination	A place where a message is to be displayed.
Details	If you have enough “details” authorization to use an application, that application will appear in the <i>SA Bar</i> for you. You will be able to use that application and view details of any data in it, but you will not be able to make any changes to it.
Device	Any hardware component attached to the computer system. Some (notification devices) are used for displaying messages.
Display	Verb: To cause a message to be shown. Noun: A device on which a message is shown.
Display command rule	Pre-defined condition(s) with resulting action(s) for how to use a variable to trigger a command to be issued. Set in <i>Variable Rule Manager</i> .
Dynamic Data Exchange	Dynamic Data Exchange, or DDE for short, is a programming method by which <i>Windows</i> -based computer applications can exchange data when running simultaneously, generally on the same computer. This way they can “communicate” directly and actions in one system can be triggered by data in another system.

External data source A source of data or information outside of the Smart Alec system. Also known as a data server. One example of an external data source could be a production line system, such as Intellution or WonderWare, providing machine statistics, like the number of parts produced per minute or a machine's temperature. Another example of an external data source could be a *Microsoft Excel* or *Lotus 1-2-3* spreadsheet.

Field One item of information about something. Examples: name, action, or destination for a display command. Compare with file and record.

File A unique, unified set of information. Examples: a Smart Alec database, a list of the event log, a source of DDE data input, a Smart Alec application. Compare with field and record.

Message A unique, unified set (file) of information – a “thought”. It can be saved and/or sent to a notification device. Its “look and feel” is based on that specific device.

A message is defined using the *Message Manager*. It may include some or all of the following properties, either specified or defaulted:

- Text
- Graphics
- Formatting (font, font size, color, etc.)
- Time/date/temperature
- Variables
- Animation

A message does not include the following, which are designated using *Command Manager* for the message:

- Scheduling
- Location/destination
- Priority

Multi-user environment	<p>A “multi-user” environment is appropriate when users should not necessarily have access to the same applications and application functions; that is, access can be restricted for some users for applications, application functions, or system inputs or resources.</p> <p>For example, you may want to restrict a clerk’s authority and not allow that person to send messages to the signs on the production floor. But you would want the building security manager to be able to send a fire alarm to every sign. Also, you might not want either of these people to be able to set authority for other users.</p>
Notification device	<p>An individual hardware component in the Smart Alec system which is capable of displaying Smart Alec messages. Examples are: ALPHA SA signs, email, and pagers. All notification devices need notification device interfaces.</p>
Notification device interface	<p>Hardware with software settings needed to communicate properly with a hardware notification device. Please see “Appendix 2: Types of Notification Device Interfaces” on page 124 for descriptions and examples.</p>
Password	<p>A special word to allow a user access to a computer application or application function.</p>
Priority, execution	<p>The level of authority needed by a user to execute a command.</p>
Priority, run	<p>The priority of a command on the display, to be compared with other commands being executed on that display. For example, two messages, each with a Run Priority of 5, will alternate on the sign. On the other hand, a message with a Run Priority of 5 will override a message with a Run Priority of 6.</p>
Record	<p>A collection of related fields. Example: all the information about one display command. Compare with field and file.</p>

SA Bar	The initial Smart Alec application and window from which you can start any other Smart Alec application for which you are authorized.
Single-user environment	A “single-user” environment in Smart Alec might have more than one user, but all users have full access rights to all applications, application functions, and system inputs and resources.
Serial address	<p>A unique number identifying one notification device in a system.</p> <p>A serial notification device interface uses cables to connect ALPHA SA signs into a network, and messages are sent over this cabling. (See “Serial interface” on page 124.)</p>
System resource	Hardware and/or data within the Smart Alec messaging system that are created and managed by Smart Alec applications. Examples are: notification devices, notification device interfaces, and variables.
Trigger	<p>Verb: Initiate, cause, start</p> <p>Noun: Something that causes an action to occur</p>
Update	<p>Adjective: If you have enough “update” authorization for an application, that application will also appear in the <i>SA Bar</i> for you. You will be able to view details and, in addition, you will be able to make changes using that application.</p> <p>Verb: To change to current value</p>
Update rate	The interval time, in milliseconds, for the OPC server to wait before updating the values of all the items in the entire Smart Alec group.
User	<p>Any person who is both authorized and set up to submit information in any way to Smart Alec.</p> <p>Each user has not only a name and password, but also is authorized for applications, system resources, data, and processing.</p>

Variable

A variable represents real-time (“as it happens”) data that can change (e.g., temperature or production rates, security lock status, alarms.) Since its value can change or vary, it’s called a “variable.” Variables’ values are typically acquired and handled by Smart Alec’s DDE or socket interfaces.

Variables can be used in two ways:

1. They can be embedded in messages. The value of the variable gets filled in wherever the variable is used in an active message, and it is refreshed whenever the value changes.
2. Variables can also be used to trigger commands for messages and events to start and stop.

As an example, you could have a variable called “Temperature” which is continually filled in with values from a thermometer. The variable could change, for instance, whenever there is at least a 1-degree change at the thermometer. Then, whenever “temperature” equals or exceeds 212° F, a message showing the temperature could be sent to a sign and an alarm could be triggered to sound.

Variable rule

A rule to govern a variable, what is done with it, and what happens when its value changes

Index

A

Administrator, Smart Alec 15, 99, 100, 102, 106, 108, 109, 158

Application

- Application Security Setup 10, 23, 108–113
- Command Manager 9, 19, 23, 66, 73, 76–82, 90, 110, 112, 160
- DDE Data Source Setup 9, 23, 47–53, 110, 112
- Display Command Group Manager 9, 23, 90–92, 110, 112
- Event Log Manager 10, 23, 110, 112, 119–122
- Message Manager 9, 15, 17, 23, 66–75, 110, 112, 160
- Notification Device Group Manager 8, 23, 87–89, 110, 112
- Notification Device Interface Setup 10, 16, 23, 110, 112, 114–118
- Notification Device Setup 8, 23, 38–41, 87, 110, 112
- OPC Data Source Setup 9, 23, 54–63
- SA Bar 8, 22–23, 34, 98, 101, 159, 162
- Smart Alec Shutdown 10, 21, 23, 33–35, 110, 112
- Socket Handler Setup 9, 64–65, 104
- System Administration 10, 23, 64, 93–95, 110, 112
- User Account Security Setup 10, 23, 101, 102–107, 109, 110, 112
- Variable Rule Manager 8, 23, 83–86, 110, 112
- Variable Setup 8, 23, 26, 42–46, 110, 112

Application Security Setup

- About 10
- Locating 23
- Using 108–113

Authorization

- Details 98, 101, 108, 111
 - Update 98, 101, 108, 111
-

C

Command Manager

- About 9
- Application names 110, 112
- Locating 23
- Uses for 66, 73, 90, 160
- Using 19, 76–82

D

Data type

- float 44, 50
- integer 44, 50
- string 44, 50, 56

DDE Data Source Setup

- About 9
- Application names 110, 112
- Locating 23
- Using 47–53

Dead band 57, 62, 159

Delta value 50, 51, 52, 57, 61, 62

Details authorization 98, 101, 108, 111

Display Command Group Manager

- About 9
- Application names 110, 112
- Locating 23
- Using 90–92

E

Environment

- Multi-user 7, 37, 102, 108, 109, 161
- Single-user 7, 37, 102, 108, 109, 162

Event Log Manager

- About 10
- Application names 110, 112
- Locating 23
- Using 119–122

Execution priority 66, 79, 161

F

Filter on 50, 51, 52, 57, 61

Float 44, 50

Function, application 24, 27, 37, 96, 97, 102, 108, 161

- Add/new 24, 27
- Change, message 72
- Change/update 24, 27, 29
- Delete 24, 27, 32

Delete, message 72
Duplicate 24, 27
View 27
View/details 24, 27, 31

I

Integer 44, 50

L

Logging into Smart Alec 15, 21, 104

M

Message Manager

About 9
Application names 110, 112
Locating 23
Uses for 160
Using 15, 17, 66–75

Multi-user environment 7, 37, 102, 108, 109, 161

N

Notification Device Group Manager

About 8
Application names 110, 112
Locating 23
Using 87–89

Notification Device Interface Setup

About 10
Application names 110, 112
Locating 23
Using 16, 114–118

Notification device interfaces 114

Notification Device Setup

About 8
Application names 110, 112
Locating 23
Using 38–41, 87

Notification devices 6

O

OPC Data Source Setup

About 9

Locating 23

Using 54–63

P

Password

Alec 103

Authorizing 105–107

Email 117

Smart Alec 15, 21, 104

Sockets 64, 104, 141, 145

Priority

Execution 66, 79, 161

Run 66, 79, 161

R

Resources, system 6, 37, 94, 96–??, 98, ??–101, 102, 161, 162

Run priority 66, 79, 161

S

SA Bar

About 8

Applications shown in 98, 101, 159, 162

Closing 34

Using 22–23

Security, system 102

About 6, 7, 10, 37

Using 96–101

Serial address 17, 39, 162

Shutting down

Complete system 35

Processor applications 34

User applications, all 34

- User applications, individual 33
- Single-user environment 7, 37, 102, 108, 109, 162
- Smart Alec
 - Password for 15, 21, 103, 104
- Smart Alec Shutdown
 - About 10
 - Application names 110, 112
 - Locating 23
 - Using 21, 33–35
- Smart Alec, logging into 15, 21
- Socket Handler Setup
 - About 9
 - Using 64–65, 104
- String 44, 50, 56
- String, initialization 116
- System Administration
 - About 10
 - Application names 110, 112
 - Locating 23
 - Uses for 64, 93
 - Using 93–95
- System resources 6, 37, 94, 96–??, 98, ??–101, 102, 161, 162

T

- Troubleshooting
 - Additional help 157
 - Hardware diagnostics 155
 - Questions and Answers 152
 - What to provide 157

U

- Update authorization 98, 101, 108, 111
- Update rate 57, 62, 162
- User Account Security Setup 101, 102, 109
 - About 10
 - Application names 110, 112
 - Locating 23
 - Using 102–107

V

Variable

- Rules 8, 163

- Variable Rule Manager

 - About 8

 - Application names 110, 112

 - Locating 23

 - Using 83–86

- Variable Setup 26

 - About 8

 - Application names 110, 112

 - Locating 23

 - Using 42–46

Variable Rule Manager

- About 8

- Application names 110, 112

- Locating 23

- Using 83–86

Variable Setup 26

- About 8

- Application names 110, 112

- Locating 23

- Using 42–46