

AlphaVision™ PC Series III 320x64 Sign Electrical Installation Guide



1

Open the side of the sign labeled "CONTROLLER SIDE".

- Disconnect all power from the sign at the power source to prevent electrical injury or damage.
- Turn the controller-side panel latches counter-clockwise. Carefully raise the panel of the sign.




▲ WARNING
Hazardous voltage.



attached to the bottom of the sign.


Open the panel identified as CONTROLLER SIDE on this label,



Connect the sign

Connect the sign and messaging computer to an Ethernet network.

- Run Category 5 T568A or T568B wire from the network into the sign communications conduit.
- Position the wires into the channels on the modular network adapter (see below).
- Use a 110 punch-down tool to push the wires into the channels.
- Do not separate the twisted pairs more than 0.5 inches from the termination point.




© Copyright 2006 Adaptive Micro Systems LLC. All rights reserved.

Adaptive Micro Systems • 7840 North 86th Street • Milwaukee, WI 53224 USA • 414-357-2020 • 414-357-2029 (fax) • http://www.adaptivedisplays.com
Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.
The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaLett, AlphaNET, AlphaNet plus, AlphaEclipse, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision
InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Serial Clock, Smart Alec, Solar, TimeNet

If applicable, connect the speakers to the Tune Blaster sound cards.

- A sign may have up to 16 speakers. Each speaker should be 8 ohms and at least 10 watts.
- For each speaker, insert one non-metallic, compression type connector into a speaker conduit.
- Run speaker wire (Belden 8471 or equivalent) from each speaker through the connector to the sound card inside the sign.
- Connect the wires to the sound card using a #1 screwdriver (1/16" wide tip) to depress the spring clip and insert the speaker wire.



Close the sign.

- Carefully lower the panel.
- Turn the latches on the panel clockwise.



WARNING Hazardous voltage.

ys disconnect power to unit prior to servicing.

COURANT DE FUITE ELEVE.

WARNING

HIGH LEAKAGE CURRENT.

supply.

Connect power to the sign.

- Make sure that power is *not* applied at the power source.
- This sign should *not* be connected to a ground fault interrupt (GFI) circuit.
- Open the circuit breaker box.
- Run one 120VAC lines into the power conduit on the side of the sign with the disconnect box.
- Connect the wires as shown below. Do not remove the yellow wires as they provide power to the fluorescent lighting circuit. The fluorescent service light is powered, even when the breaker box is open. The sign must be properly earth grounded.
- Close the breaker box. Apply 120VAC power at the power source. Then move the breaker switch to the ON position.
- Confirm that the green indicator light is lit, indicating that power is supplied to the sign.

