



---

<b>PRIORITY:</b>	Normal
<b>DATE:</b>	October 13, 2004
<b>TITLE:</b>	AlphaEclipse 3600 Controller Board LEDs
<b>ECO REFERENCE:</b>	n/a
<b>PRODUCT(S) AFFECTED:</b>	AlphaEclipse 3600 Series A and B signs
<b>SUMMARY:</b>	This document provides information on the location and meaning of the diagnostic LEDs on an AlphaEclipse 3600 Series A or B controller board.

---

---

© Copyright 2004 Adaptive Micro Systems LLC. All rights reserved.

Adaptive Micro Systems • 7840 North 86th Street • Milwaukee, WI 53224 USA • 414-357-2020 • 414-357-2029 (fax) • <http://www.adaptivedisplays.com>

Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.

The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaLert, AlphaNET, AlphaNet plus, AlphaEclipse, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Serial Clock, Smart Alec, Solar, TimeNet.

The distinctive trade dress of this product is a trademark claimed by Adaptive Micro Systems LLC.

Due to continuing product innovation, specifications in this manual are subject to change without notice.

There are 15 diagnostic LEDs on an AlphaEclipse 3600 Series A or B controller board:

