



PRIORITY:	Normal
DATE:	June 20, 2005
TITLE:	RS485 Termination for AlphaEclipse RoadStar and AlphaEclipse 3600 Signs
ECO REFERENCE:	n/a
PRODUCT(S) AFFECTED:	AlphaEclipse RoadStar and AlphaEclipse 3600 signs
SUMMARY:	The purpose of this document is to explain how to terminate RS485 networks.

Related documentation

Part #	Title
9711-7502	AlphaEclipse RoadStar Service Manual
9711-5001	AlphaEclipse RoadStar Install Manual
9711-8009	AlphaEclipse 3600 Service Manual
9711-8028A	AlphaEclipse 3600 Install Manual

RS485 termination

Shown below are the RS485 termination diagrams for the AlphaEclipse RoadStar and the AlphaEclipse 3600 networks.


© Copyright 2005 Adaptive Micro Systems LLC. All rights reserved.

Adaptive Micro Systems • 7840 North 86th Street • Milwaukee, WI 53224 USA • 414-357-2029 (fax) • <http://www.adaptivedisplays.com>
Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.

The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaLert, AlphaNET, AlphaNet plus, AlphaEclipse, AlphaEclipse RoadStar, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Serial Clock, Smart Alec, Solar, TimeNet.

The distinctive trade dress of this product is a trademark claimed by Adaptive Micro Systems LLC.
Due to continuing product innovation, specifications in this manual are subject to change without notice.

AlphaEclipse 3600 RS485 Termination



AlphaEclipse RoadStar RS485 Termination

